































ASSEMBLY INSTRUCTION

This installation manual is the correct version


Note: Distinguishing between the numbers 6 and 9 is different, with the number 9 underlined; Please tighten all screws by 60% first, and then tighten them by 100% after installation is complete.




1.x2 	2.x2 	3.x2 	4.x2 	5.x1 
6.x1 	7.x1 	8.x1 	9.x10 	10.x1 
11.x10 	12.x1 	13.x2 	14.x2 	15.x3 
16.x1 	17.x2 	18.x4 	19.x2 	20.x2 
21.x1 	22.x2 	23.x1 	24.x1 	25.x1 
26.x1 	27.x1 			

A.x16pcs  M8x55mm	B.x32pcs  M6x55mm	C.x31pcs  M6x35mm	D.x1pcs  M6	E.x8pcs  M8
F.x3pcs  M6	G.x16pcs  M8x22mm	H.x27pcs  M6x16mm	I.x36pcs  M6x16mm	J.x1pcs  M6
K.x1pcs  M8	L.x1pcs  5#	M.x1pcs  4#	N.x8pcs  Ø38	O.x40pcs 
P.x4pcs 	Q.x1pcs  20x20mm			


①




②




③




④




5




6






7







8




9




10




11




12



13



14



15

