



ASSEMBLY INSTRUCTIONS




ASSEMBLY INSTRUCTIONS

Parts List


Ax1




Cx1




Ex1




Fx4




Bx4



Dx1




Gx4




Hardware List


Hx16




Jx16




Lx1



Ix16




Kx17



ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2

