

CARE INSTRUCTIONS

BEFORE USE

- Foam is sensitive to temperature. When exposed to colder temperatures your Bean bag will become firmer. Your body heat will help the foam soften.
- External heat source, not recommended on the Bean Bag doing so will damage the Bean Bag.
- New foam may initially have a slight odor: it is completely harmless and will dissipate over a short time with regular use.
- To expedite odor dissipation, remove and wash the cover and place the inner content in a dry sunny location.

WASHING CARE

- Pre-wash the zippered cover before first use.
- Wash zippered cover separate from other items as zipper may cause damage to clothing or linens.
- Wash the zippered cover in cold water using a non-chlorine bleach detergent on a gentle cycle with cold water rinse.
- The Bean Bag can be spot cleaned with mild detergent by hand wash only; do not soak or machine wash the foam. Rinse with warm water.

DETERGENT

- Use a mild liquid detergent, preferably non alkaline, without added bleach or whiteners.

DRYING CARE


- Tumble dry zippered cover on low heat.
- Never use a high heat setting or over dry; this will weaken the fibers, cause shrinkage and or shorten the life of the cover.
- After spot cleaning the Bean Bag dry at room temperature away from heat or light. Do not machine wash or dry.

ZIPPER INSTRUCTIONS

1

OPEN REMOVABLE COVER


Open cover using paper clip, as the pull on the slider has intentionally been removed for children safety.



2

PLACE REMOVABLE COVER ON FILLER


Once you have opened your cover, place this on the filler that should be inflated at this time.



3


CLOSE REMOVABLE COVER

Follow the process for opening the cover to now close the zipper.




Setup Instructions


What You Need:
Paper Clip, Scissors, and a Friend!




1
Have a friend help to remove your beanbag from the box




4
Orient the EcoFoam case so it resembles the finished product.




2
Take the fabric cover from its' package and locate the zipper. Use your paper clip as a pull tab by threading one end through the slider body. Set aside.



5
Open the cover completely and slide it over the beanbag. The zipper should be on the bottom.



3
Use your scissors to carefully remove the layers of plastic encapsulating the case of EcoFoam stuffing.



6
Adjust the stuffing inside the case, breaking up any lumps of EcoFoam, then zip to close. Give the bean bag 6 hours to air out and expand, then enjoy!