



ITEM #: RV-F4131 / RV-F37-354131

IMPORTANT SAFETY INSTRUCTIONS

- To avoid injury or damage, mount only on a surface that is sturdy.
- To avoid electric shock, make sure the electricity is turned off at the main circuit breaker panel. If you are replacing an existing fixture, turn off the following in order: fixture, wall switch, and main fuse or breaker box.
Note: Some types of fuses must be unscrewed to shut the power off.
- If you are unclear as to how to proceed, please consult a licensed electrician.

UNPACK THE LAMP: Check the contents of the box. Box should contain all items on the parts diagram.




For any replacement parts or installation issues, please Contact Us!

Email: help@kira-home.com

Facebook/Instagram: @KiraHomeDecor

Phone: 888.208.2085



ASSEMBLY INSTRUCTIONS

1. Secure (4) Long Legs (C) to Base (B) using (4) Screws (A).
2. Attach Shelf (E) to Legs (C) with (4) Double-Sided Screw Bolts (D). Secure all sets of Legs (C) and Bolts (D).
3. Secure Socket (H) to Top Shelf (G) with Wing Nut (F). Secure Top Shelf (G) to Legs (C) with (4) Screw Bolts (D).
4. Attach (4) Short Legs (J) to Top Shelf (G) onto Screw Bolts (D).
5. Attach Frame (K) to Legs (J) with (4) Screws (A). Insert (4) Dowels (I) into holes on Top Shelf (G). Unfold Shade (L) and insert into Frame (K).
6. Insert Bulb (N) into Socket (H).
7. Affix cord to frame with Straps (O). Secure Foot Pads (M) to bottom of Base (B).

Enjoy your new lamp!