




The Dining Chair Installation Instructions

List of Accessories


NO	Description		QTY
A	Seat		4
B1	Upper Leg		4
B2	Lower Leg		4
C	X-bracket		4
D	Bolts M6×(50mm)		8
E	Bolts M6×(40mm)		8
F	Short bolts		16
a1	Washers		32
a2	Caps		16
b	Allen Key		1
c	Foot pads		16

Warnings:


- Read the instructions carefully before assembly. Do not use the product until it is fully assembled.
- Use on flat ground only.
- Do not stand on the product.
- Dispose of damaged products properly.
- Indoor use only.
- Keep the instructions for future reference.




1. Join leg (B1) and leg (B2) together, then use short bolts (F)*4 and Washers (a1)*4 to secure the X-bracket (C) to the legs using allen key(b).



3. Invert seat (A). Ensure the side with the longer extension points forward. Attach the leg base underneath. Partially tighten 4 pcs of washers (a1) using M6x50 bolts (D) (front) and M6x40 bolts (E) (back) with the Allen key



2. Tuck the Caps (a2)*4 into the top of the legs
Note: the front-to-back orientation of the integrated cross legs, the longer side faces forward, and the shorter side faces backward.



4. Tighten the Foot Pads(G)*4 to the bottom of the legs, installation complete.