Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



• Not for commercial use. For residential use only.



• Furniture may scratch floors. We recommend using furniture pads to protect your floors.



Do not put hot items directly on furniture surface.



• Do not clean furniture with harsh cleansers or polish.



• Do not place furniture under direct sunlight.



• Do not place furniture near heating or cooling vents.



• Do not write on furniture without a padded barrier to protect the surface.



• Do not place furniture outside . For indoor use only.



 Stains may be removed with mild soap solution and damp cloth.




• Children should not climb or jump on the furniture.



• Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Chair for hardware packs and legs. Sets often ship in multiple boxes and may arrive a day or two apart.

COUNTER STOOL



Parts List


l ala al	Dieture	Decemention	O.T.) (
Label	Picture	Description	QTY
Α	<i>⟨</i>	Left front leg	1
В	<i>⟨</i>	Right front leg	1
С	*	Stretcher lower front leg	1
D		Stretcher the upper front leg	1
E	(· · · · · ·	Left back leg	1
F	(<u>••</u>) • • • • • • • • • • • • • • • • • •	Right back leg	1
G	<i>(</i> € − − − − − − − − − − − − − − − − − − −	Stretcher the back leg	2
Н	←	Lower middle leg stretcher	2
I	6	Right Upper middle leg stretcher	1
K		Left Upper middle leg stretcher	1
L		Seat Frame With Cushion	1
M		Back Frame	1

Hardware

Label	Picture	Description	QTY
1		Bolts (M6x40MM)	16
2		Bolts (M6x30MM)	4
3		Bolts (M6x25MM)	4
4	3	Spring Washer (Ø1/4*10MM)	24
5		Flat Washer(Ø1/4"x13MM)	24
6	9////	Wood dowel (Ø6*40MM)	16
7	(†)200000000>	Wood screws(Ø4*35MM)	4
8		Allen key (100*30*4MM)	1
9	Θ	Wooden Plugs (Ø16x7MM)	8
10		ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)	1

Assembly Preparation

Before Beginning Assembly:





① x 16

② x 4

③ x 4 ④ x 24

⑤ x 24

(6) x 16

① x 4 ⑧ x 1

9 x 8



Read instructions, cover to cover-



Have 2 adults on hand for assembly-



· Do not assemble on flooring or carpet-




• Assemble on a clean non-marring surface (packing foam)-



Save all packaging until finished-


Assembly Steps

Overview



This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

STEP 1



① x 16

② x 4 ③ x 4

④ x 24


⑤ x 24

⑥ x 16

⑦ x 4 ◎ 8 x 1


(9) x 8

Unpack and place all parts on a clean, non-marring surface.




Assemble the Stretcher lower front leg (C), Stretcher the upper front leg (D) into the Left front leg (A), Right front leg (B), using the wooden dowel (6), bolt (1), Spring Washer (4) flat washer (5), Allen key (8). **Do not fully tighten Bolts at this time.**

STEP: 3




Assemble the Stretcher the back leg (G),into the Left back leg (E),Right back leg (F),using the wooden dowel (6), bolt (1), Spring Washer (4) flat washer (5), Allen key (8). **Do not fully tighten Bolts at this time.**




Assemble the Lower middle leg stretcher (H), Right Upper middle leg stretcher (I) Left Upper middle leg stretcher (K), into the part in step (3), using the wooden dowel (6), bolt (1), Spring Washer (4) flat washer (5), Allen key (8). **Do not fully tighten Bolts at this time.**

STEP: 5




Assemble the part in step (4), into the part in step (2), using the wooden dowel (6), bolt (1), Spring Washer (4) flat washer (5), Allen key (8). **Do not fully tighten Bolts at this time.**




Assemble the Seat Frame With Cushion (L), into the part in step (5), using the Wood screws (7). Do not fully tighten Bolts at this time.

STEP: 7



Assemble the Back Frame (M), into the part in step (6), using the bolt (2) for the front and (3), for the back , Spring Washer (4) flat washer (5), Allen key (8).

Do not fully tighten Bolts at this time.



Place the Chair on a level Surface to check if it wobbles.

If it wobbles, lift the Chair some 30cm to 50cm above the ground.

Keep your feet and toes well away from the drop zone.

Drop chair freely and vertically, with the four legs hitting the ground at the same time.

This Drop Test will help to ensure that all the Bolts and gaps reach full alignment status.

Test again for evenness on a Level Surface.

If no wobbles are found, proceed to tighten all the Bolts.


When tightening the Bolts, tighten sequentially.

Do not fully tighten any bolt fully and then move towards the next one.


This may cause the frame to warp.

If there are still wobbles after tightening, loosen the Bolts and execute this same drop test

STEP: 9



Close the Wooden Plugs (9) tightly to the previous bolt catch hole.



This Chair can only be used on a flat, level surface.