


Assembly instruction











1760X760




Important

If you need help or have damaged or missing parts,
please call the Customer Helpline

Hardware


A  34PCS	B  34PCS	C  06PCS
D  06PCS	E  12PCS	F  01PC
G  34PCS	I  44PCS	
J  13PCS	K  02PCS	

Components - panels




Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3




Step 4




Assembly Instructions

Step 5




Step 6



Assembly Instructions

Step 7



Step 8

