


ASSEMBLY INSTRUCTION



+ Do Not Use Power Tools




+ Suggested Adults




+ Parts Included


① SOFA BASE
1PC



② CHROME FRONT LEG
2PCS




③ GOLD FRONT LEG
2PCS



④ CHROME BACK LEG ⑤ GOLD BACK LEG
2PCS 2PCS



⑥ FOOT PAD
8PCS



⑦ MIDDLE LEG
1PC



+ Hardware Included

A ALLEN WRENCH
Ø5/16 *66MM 1PC



B BOLT
M6*70MM 8PCS



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

- Part # - Sofa Base
- Part # - Chrome Front Leg
- Part # - Gold Front Leg
- Part # - Chrome Back Leg
- Part # - Gold Back Leg
- Part # - Foot Pad
- Part # - Middle Leg

Do not assemble if any of the following

Hardware parts missing:




- Part # - Allen Wrench
- Part # - Bolt

2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

ASSEMBLY INSTRUCTION

1



2



3

