



User Manual for Obelisk Pyramid-7.8ft

Models: VPSSOPLDG

Gardening Made Easier. Anytime, Anywhere.

Copyright © 2026 Vego



**Gardening
Made Easier.
Anytime,
Anywhere.**

Contact Us



+1 (866) 597-1888



Vego Garden Academy



hello@vegogarden.com




vegogarden.com




vego_garden



Houston, TX



Parts List



Safety Precautions

This product may contain sharp metal corners and edges. To prevent injury:

- Handle with care at all times
- Wear gloves, closed-toe shoes & long pants when handling
- Work on a stable, clean surface away from children and pets
- Follow all instructions carefully and use tools only as directed

If you are unsure about any step, pause and seek assistance.




Assembly Guide

- 1 Position P2 and P3 so the arches cross and overlap at the center, aligning the pre-drilled holes. Insert the F1 screw and secure it with the F2 ball finial. Tighten the connection 3-4 turns only.


Notes:

Make sure P3 is on top and P2 is on the bottom.


Do not fully tighten at this stage – leaving the connection slightly loose allows for easier alignment and adjustment in later steps.






- 2** Install the first tier as shown in the diagram. Insert the threaded ends of P1 rods into the holes at the four corners of P4, then secure them by screwing in the arched ends. After all four P1 rods are securely installed, tighten the F1 and F2 from the previous step.



- 3** Following the sequence shown, install the remaining tiers in the following order: P5 → P6 → P7 → P8 → P9.



- 4** Install the Way You Need-WITHOUT GROUND SPIKES
As shown in the diagram, replace the bottom four P1 rods with F1 screws.



⚠ Alignment Check

After assembly, check each tier from top to bottom to ensure all rods are fully tightened.

Lay the obelisk flat on the ground and confirm each side sits evenly and flush with the surface.

If needed, gently adjust by hand to correct the alignment and ensure the frame is level and properly aligned before placing it upright.

🌿 Important

For your safety, please ensure the structure is securely fastened. In windy areas, be sure to anchor your Obelisk firmly to the ground. This will keep strong winds from tipping it over and harming your plants.

🌿 Maintenance and Care

- Clean with a soft cloth, use mild soap and water if needed.
- Do not use abrasive cleaners or harsh chemicals.
- Avoid prolonged contact with standing water or constantly wet soil.
- If the surface coating is scratched, touch up promptly with rust-resistant outdoor metal paint.
- In inclement weathers, clean, dry, and store indoors at the end of the season.
- Periodically check and retighten fasteners as needed.

🌿 Warranty and Support

Warranty: 3 Years Structural Guarantee

Exclusions: Damage caused by misuse, improper installation, or modifications is not covered.

Customer support

For any issues, please contact our customer support team via:

Email: hello@vegogarden.com

Website: www.vegogarden.com