



11 1 	2 	3 	4 
21 1 	2 	3 	4 
5 	6 	7 	8 
9 	10 	11 	
12 	13 		

1 General warnings

Read all the instructions and warnings carefully before using this product. Failure to follow warnings and instructions can result in severe injury, death, or property damage. Before installation, check if all accessories are complete and without damage. If not, contact customer service. Keep these instructions in a safe place for future reference. Use this product with its original parts only. vidaXL cannot be held responsible in the event of damage or injury due to incorrect use of this product. The information contained in this manual is believed to be correct at the time of printing. However, vidaXL reserve the right to change or modify any of the specifications without notice or obligation to update existing units. Repairs should only be carried out by a specialist or a professional and experienced technician. Never attempt to repair the product yourself.

2 Introduction

This product is designed for Christmas decoration and should be used for this purpose only.

3 Symbol clarification

See image 1

1. Caution! Risk of electric shock!
2. CE logo.
3. WEEE with bar.
4. LVD Class III symbol.

4 Warnings and personal safety

- Do not connect this product to any power supply or adapter other than the one described in the manual, the name plate or specifically recommended by VidaXL.
- This product must not be used by children below 14 years, persons with special needs or reduced physical, sensory or mental capabilities and lack of experience concerning the use of electronic appliances.

- Electricity is dangerous. Damage and improper use or alteration such as replacement of the individual components can lead to the product damage and the mains wiring, resulting in electric shock and serious injuries to the user.
- DO NOT operate this product in the presence of explosives such as flammable liquids, gases and dust or in the extreme temperatures and above 50 degrees Celsius.
- DO NOT switch on the product if the connecting cable or the adapter is visibly damaged.
- DO NOT open or insert anything into the electrical fittings or the equipment. Doing this can lead to serious danger and even electric shock.
- If the external flexible cable or cord of this luminaire is damaged, contact an experienced technician or an authorised service centre for a replacement to avoid a hazard.
- Turn off the power during installation and maintenance. Make sure the bulbs have cooled down.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the replace the product.
- This product is intended for outdoor use.

5 Assembly instructions

See image 2

6 Maintenance and cleaning

Always use a dry and soft cloth to clean the product. Do not use any cloth dipped in paint, organic solvent or chemicals. Always disconnect the product from the mains supply or turn off the mains supply when not in use and while cleaning.

7 Technical specifications

Voltage	Power
DC5V	3W