

4-Light Linen Drum Ceiling Light

Caution: Please turn off power before installation and read the manual carefully, we advise you contact professional electricians to install for safety purpose.

Product Features

Style: Modern/Contemporary/Farmhouse/Bohemian

Material: Metal, Linen

Base Type: E14

Light Source Included: No

Voltage: 230VAC


Wattage: 40W

Package includes

1 x Ceiling Light

1 x Accessories Kit

1 x User's Manual



Installation Instructions

1. Assemble the bulbs (not included).
2. Screw the down-rod onto the top of the fixture body.
3. Place the canopy onto the top section of the down-rod.
4. Drill two holes in the ceiling and insert the ribbed plastic anchors into the holes.
5. Attach the mounting back-plate to the ceiling using provided screws.
6. Connect the fixture wires and earth/ground wire to the ceiling wires. Ensure that the neutral, live, and earth/ground wires are correctly matched.
- 7-8. Cover the mounting back-plate with the canopy and secure with cap nuts.

Note: please use this product accordingly to its intended purpose, do not retrofit or remodeling the product. The warranty does not cover if the failure is caused by the third party product, or natural disasters.