

ASSEMBLY INSTRUCTIONS:

VERY IMPORTANT :

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY.

Carefully unpack this lamp and place it on a flat surface.

1. Carefully unpack and place all lamp parts on a flat surface.
2. Screw Lower Pole (B) onto Base (A), and then screw Center Pole(C) onto Lower Pole (B).
3. Screw Upper Pole (D) onto Center Pole (C) then straighten the cord from Base (A).
4. Put the Bigger Glass Shade (E) onto the lamp socket and secure with Socket Ring (F) until tight.
5. Attach Smaller Glass shade (I) onto Lamp Holder (H), secure with Socket Ring (J) until tight.
6. Install Bulb (G) & (K) into the sockets then insert the polarized plug into a wall outlet and enjoy.
7. Use only a soft dry cloth to clean. Never use chemical or abrasive cleaners.

Use 1pc 32W & 1pc 13W CFL Bulb or 1pc 150W & 1pc 60W (Maximum) incandescent A Type bulb.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.

ATTENTION

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES À FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

