

GRACE PRINCESS DOLLHOUSE (WDH01)

Assembly Instruction

*Please follow this instruction to avoid assembly errors.

*For customer service, please contact **E-mail: shop@robud.com**



98.1WDH01.150

⚠ WARNING:


CHOKING HAZARD-Small parts. Not suitable for children under 3 years.

Toys intended to be assembled by an adult. Children should use the product under adult's guidance.


After opening the package, please keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.

<p>1</p> <p>x1</p>	<p>2</p> <p>x1</p>	<p>3</p> <p>x1</p>	<p>4</p> <p>x1</p>
<p>5</p> <p>x1</p>	<p>6</p> <p>x1</p>	<p>7</p> <p>x1</p>	<p>8</p> <p>x1</p>
<p>9</p> <p>x1</p>	<p>10</p> <p>x1</p>	<p>11</p> <p>x1</p>	<p>12</p> <p>x1</p>
<p>13</p> <p>x2</p>	<p>14</p> <p>x1</p>	<p>15</p> <p>x1</p>	<p>16</p> <p>x1</p>
<p>17</p> <p>x26</p>	<p>18</p> <p>x10</p>	<p>19</p> <p>x4</p>	<p>20</p> <p>x2</p>


1




2




3



4



5



6

