



ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



Allen Wrench

(Included)



2 - People
Recommended

ASSEMBLY RATING




EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS

#1 1pc






Table Top

#2 1pc



Leaf

#3 2pcs



Mounting Plate

#4 1pc




Table Base

HARDWARE

#A 12pcs



Bolt $\text{Ø}5/16'' \times 1-1/2''$

#B 12pcs



Lock Washer
 $\text{Ø}5/16''$

#C 12pcs




Flat Washer
 $\text{Ø}5/16''$









#D 1pc



Allen Wrench
4mm



CM3337T is packed in 2 cases

Carton	Disignation	Part		Hardware
CM3337T-1	Table Top	#1		 #A x 12pcs  #B x 12pcs  #C x 12pcs  #D x 1pc
	Leaf	#2		
	Mounting Plate	#3		
CM3337T-2	Table Base	#4		

ASSEMBLY INSTRUCTIONS

1

Part (#3) x2pcs


Part (#4) x1pc

Hardware (#A) x4pcs

Hardware (#B) x4pcs

Hardware (#C) x4pcs

Align mounting plates (#3) to table base (#4), then secure by using bolts (#A) with washers (#B,C).



2


Part (#1) x1pc

Hardware (#A) x8pcs

Hardware (#B) x8pcs

Hardware (#C) x8pcs

Align mounting plate (#3) on the table base (#4) to table top (#1), then secure by using bolts (#A) with washers (#B,C).




ASSEMBLY INSTRUCTIONS

3


Part #2 x1pc

Turn lever to open underneath the table top, then extend and fit the table leaf (#2) onto the table top (#1).



4

Turn the lever to lock.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




Lift, don't drag!


To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

CHAIR

CM3337SC-2PK




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc x2




Chair Back

#2 1pc x2



Cushion Seat

#3 2pcs x2



Front Leg


HARDWARE

#A 2pcs x2



Bolt $\text{\O}1/4'' \times 1-5/8''$

#B 4pcs x2



Bolt $\text{\O}1/4'' \times 2-3/8''$

#C 4pcs x2



Bolt $\text{\O}1/4'' \times 3''$

#D 10pcs x2




Lock Washer
 $\text{\O}1/4''$

#E 10pcs x2




Flat Washer
 $\text{\O}1/4''$

#F 1pc



Allen Wrench
4mm




x2

ASSEMBLY INSTRUCTIONS

1

- Part #1 x1pc
- Part #2 x1pc
- Hardware #A x2pcs
- Hardware #D x2pcs
- Hardware #E x2pcs

Align seat (#2) to chair back (#1), then secure two middle holes by using bolts (#A) with washers (#D,E).




x2

2

- Hardware #C x4pcs
- Hardware #D x4pcs
- Hardware #E x4pcs

Secure corner holes of the seat (#2) to chair back (#1) by using bolts (#C) with washers (#D,E).



x2

ASSEMBLY INSTRUCTIONS

3


Part (#3) x2pcs

Hardware (#B) x4pcs


Hardware (#D) x4pcs

Hardware (#E) x4pcs

Align front legs (#3) to the seat (#2), then secure by using bolts (#B) with washers (#D,E).



4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.