

Installation Instructions


TABLE LAMP

ASSEMBLY INSTRUCTIONS :

1. PUT "2" ONTO "1"
2. PUT "3" ONTO "2"
3. TIGHTEN "3" BY "4"
4. SCREW "5" ONTO "4"
5. PLEASE USE 40 WATT Edison BULB.
(BULB INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.



Instructions d'assemblage

LAMPE DE TABLE

INSTRUCTIONS D'ASSEMBLAGE

1. METTRE "2" DANS "1"
2. METTRE "3" DANS "2"
3. RESSÉRER "3" AVEC "4"
4. VISSER "5" DANS "4"
5. Ampoule Edison 40 W MAXIMUM.
(AMPOULE COMPRISE)

MESURES DE SÉCURITÉ IMPORTANTES

CETTE LAMPE PORTATIVE A UNE FICHE POLARISÉE (UNE BROCHE PLUS LARGE) AFIN DE RÉDUIRE LE RISQUE DE DÉCHARGE ÉLECTRIQUE. CETTE FICHE NE S'INSÈRE DANS LA PRISE QUE D'UNE SEULE FAÇON. SI LA FICHE NE RENTRE PAS COMPLÈTEMENT DANS LA PRISE, INVERSEZ LA FICHE. SI ELLE NE RENTRE TOUJOURS PAS, CONTACTEZ UN ÉLECTRICIEN QUALIFIÉ. NE JAMAIS UTILISER UNE RALLONGE SI LA FICHE NE PEUT ÊTRE ENTIÈREMENT ET FACILMENT INSÉRÉE. **NE PAS MODIFIER LA FICHE POLARISÉE.**

