


BOOKSHELF





ASSEMBLY INSTRUCTIONS





WARNING

Children have died from furniture tip-over. To reduce the risk of furniture tip-over:



- ALWAYS install tip-over restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawer.



We recommend at least 2 people for the assembly.




To prevent any damage during assembly, place a mat under the pieces.




BOOKSHELF PARTS

 Check if all parts and hardwares are included.




HARDWARE KIT

 The plus numbers are the additional parts provided in case of missing or damaged ones.



CAM LOCK FASTEN SYSTEM


 Insert the cam bolt into the hole, then insert the cam lock and tighten.



ASSEMBLY


01

A x2 B x2 C x2 E x4 I x2




02

A x6 B x6 C x6 D x6 F x1




03

A x6 B x6 C x2 G x2




04

A x2 B x2 C x8 D x11 G x2 E x2 I x1




05

A x6 B x6 F x1




06

A x6 B x6 C x2 G x2




07

A x2 B x2 C x8 D x11 G x2 E x2 I x1




08

A x6 B x6 F x1




09

A x6 B x6 C x2 G x2





10

A x2 B x2 C x8 D x11 G x2 E x2 I x1





11

K x6




12

E x2 H x2 D x2 J x2



Flip Over



2 sets of tip-over restraint are included. To install the other set, you may need to drill a new hole.

Tips:
Assemble from the top to the bottom. However, disassemble from the bottom to the top.