





Assembly Instructions





Dining Table



We recommend using hand tools for assembly.

If an electric screwdriver is used, reduce power and torque to avoid damage to the product.







⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for a free replacement if you encounter any damaged or missing parts.


Parts List




❶ 2 pcs




❷ 1pc




❸ 2 pcs



❹ 2 pcs






❺ 4 pcs




❻ 1pc

Hardware List


A	X24+1	B	X24+1	C	X32+1	D	X2+1	E	X8+1
									
Ø6X35 mm		Ø15X12 mm		Ø8X30 mm		Ø10X50 mm		Ø7X47 mm	

F	X8+1	G	X12+1	H	X4	I	X1
							
Ø7X67 mm		M6X30 mm		M6XØ30 mm		M4X64 mm	


1



X2

A	X24
	
Ø6X35 mm	


2



X2

B	X12	C	X8
			
Ø15X12 mm		Ø8X30 mm	


3




X2


B	X12	C	X8
			
Ø15X12 mm		Ø8X30 mm	


4




C	X8	E	X8	I	X1
					
Ø8X30 mm		Ø7X47 mm		M4X64 mm	

5




C	X8	F	X8
			
Ø8X30 mm		Ø7X67 mm	

6




H	X4
	
M6XØ30 mm	

7



D	X2
Ø10X50 mm	

8



G	X12
M6X30 mm	

Thank you for your support!

