
ASSEMBLY INSTRUCTION



Size: 36" X 60" X 30"H

List of Part For 1 Set

Code	Figure	Part	Qty.
1		Table Top	1
2		Leg	4

List of hardware For 1 Set

Code	Figure	Hardware	Qty.
a	0	Flat Washer 5 x 22mm	8
(b)	Ø	Spring Washer 5 16"	8
©	©	Hexagon Nut 5 16" x 7mm	8
(d)	2/	Spanner 12.8mm	1

Important Notes

- * Keep all hardware parts out of reach of children.
- Must tighten screws periodically.With use screws will become loose.Check tightness of all screws every 6-8 weeks.
- * Don't attempt to repair or modify parts that are broken or defective.Please contact he store immediatedly.
- * Do not tighten all screw / bolt until all completly assembled


Notes

- * Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- * Check to be sure that you have all parts and hardware.
- *Remove all wrapping materials including staples & packing straps before you start to assemble.

Care And Maintenance

- * Do not put hot pan or hot pot on table top directly and please use isolated pad.
- * The Touch of a soft cloth is all the maintenance your wood pieces will ever need.
- Never use harsh chemicals or abrasive cleaner as they could mark or destroy finish.

ASSEMBLY INSTRUCTION



SIZE: 18 1/2" x 24" x 34 1/2" H

List of Part For 1 Set

Code	Figure	Part	Qty.
1		Chair Back	1
2		Cushion Seat	1
3		Front Leg	2

List of hardware For 1 Set

Code	Figure	Hardware	Qty.
A		Hex.Bolt M6 x 80mm	4
B	3	Hex.Bolt M6 x 60mm	4
©	-	Hex.Bolt M6 x 40mm	3
D	0	Flat Washer	11
E	0	Spring Washer	11
F	ß	Spanner 10mm	1



- * Keep all hardware parts out of reach of children.
- Must tighten screws periodically. With use screws will become loose. Check tightness of all screws every 6-8 weeks.
- Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediatedly.
- Do not tighten all screw / bolt until all completely assembled.

Notes

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- * Check to be sure that you have all parts and hardware.
- * Remove all wrapping materials including staples & packing straps before you start to assemble.

Care And Maintenance

- * The Touch of a soft cloth is all the maintenance your wood pieces will ever need.
- * Never use harsh chemicals or abrasive cleaner as they could mark or destroy finish.