



CB1500

**COLD
BREW**
IMMERSION
COFFEE MAKER

Better Coffee, Made Easy

— THE —
LONDON SIP

Cold Brew Immersion Coffee Maker

Thank you for purchasing the London Sip Cold Brew Immersion Coffee Maker. Please read the following manual carefully before using your Coffee Maker to ensure proper use and care. If you have an issue with your Coffee Maker, please contact London Sip at **1-800-467-6408** to speak with a product specialist. We would appreciate the opportunity to resolve any issues you may have before returning the product to the retailer.

DIAGRAM & ASSEMBLY

1. Locking Lid:

↺ twist *counterclockwise* to unlock

↻ twist *clockwise* until click to lock

2. Removeable Top

3. Housing/Handle

4. Glass carafe

5. Stainless Steel Filter



Making Cold Brew Coffee

The process for making cold brew in your coffee maker is simple but the grind size, coffee to water ratio, etc. are all factors that have to be considered when making cold brew.

Some experimentation will be necessary until you achieve what you consider your ideal cup of cold brew. The information given below is a great place to start and can be adjusted to your preferred taste. Brew lighter for ready to drink cold brew without the need to dilute or brew stronger to account for dilution when adding ice, milk, etc. We also recommend the use of a scale for best results.

Coffee to Water Ratio: 1:13 (1g of coffee for every 13g of water)

Grind Size: Coarse (freshly ground coffee is recommended)

Water Temperature: Cold or Room Temperature

Brew Time: 24 hours

Note: This is a slightly stronger brew strength to allow for dilution with ice, water, milk, etc.

For the example below we are assuming a 1:13 coffee to water ratio.

To brew coffee, place the stainless steel filter inside the carafe and pour 100g of coarse ground coffee into the filter. Slowly pour 300g of cold or room temperature water over the grounds to dampen. Slowly pour an additional 1000g of water into the carafe to cover the coffee grounds to reach a total of 1300g of water. Give the coffee a gentle stir until the grounds are fully saturated with water. Place the lid on the carafe, place in the refrigerator, and let the coffee brew for 24 hours. For best extraction we recommend stirring the grounds during the brewing process. After 24 hours, remove the stainless steel filter from the carafe and clean thoroughly. Pour cold brew into a glass, add ice, milk, cream, or sugar to your liking, and enjoy. Store the cold brew in the carafe or transfer to another clean vessel.

Filter Cleaning/Descaling

Daily Cleaning

Your filter should be cleaned after each use and deep cleaned/descaled regularly to ensure that it works properly and does not impart flavors to your coffee. To clean your filter, remove it from the carafe and wash well to remove any coffee residue or coffee oils. Let the filter dry thoroughly and then store or insert back into the carafe.

Deep Cleaning

Your filter will not function properly if it is not deep cleaned/descaled regularly. Overtime coffee residue and scale can build up on the filter and reduce the water flow and flavor of your coffee. Scale is a naturally occurring buildup of mineral deposits caused by impurities in water or use of hard water. The ideal timeframe for cleaning and descaling your filter will depend on water hardness. We recommend that the filter be deep cleaned and descaled every few weeks for optimal performance. Descal your filter utilizing a descaling solution available at most retailers. Follow the directions included with the descaling solution for optimal results.

Safe Use and Care

- FRAGILE - Handle the coffee maker with care to avoid breaking/shattering the glass.
- Please use the coffee maker for its intended purpose only.
- Never use the coffee maker directly over an open flame or directly on an electric burner.
- Never use the coffee maker in an oven or microwave.
- Do not let children near the coffee maker when in use.
- Hand wash each part thoroughly with warm water, avoiding the use of detergent.

The use of detergent can impart flavors to your beverages.

- Do not clean the carafe or filter in the dishwasher
- Ensure that the product has dried out completely after washing and before storing.

Use a clean dry cloth if necessary.

- To prevent damage to the carafe and filter when cleaning, do not use abrasive pads, harsh chemicals, or other cleaning agents.

SPECIFICATIONS:	
Carafe Construction	Borosilicate Glass / Plastic
Filter Construction	Stainless Steel
Carafe Capacity	1500ml / 50.7 oz (without filter)
Filter Capacity	120g of coffee grounds
Dishwasher Safe	No – Handwash only
Dimensions (L x W x H)	4.8 x 7.08 x 8.46 in. / 122 x 180 x 215 mm
Weight	23.46 oz / 665 g

PRODUCT SUPPORT

Email support: info@thelondonsip.com

Phone support: 1-800-467-6408



Lifetime Limited Warranty

Your product is warranted to be free of manufacturing defects for the lifetime of the product. This warranty does not cover breakage, spare or consumable parts, misuse, abuse, or general wear and tear. For more details visit: TheLondonSip.com/warranty

The London Sip's liability is limited to two (2) times the cost of the product.