

## WARRANTY


We strive to offer high-quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.

**Are you having difficulty  
with assembly? Missing parts?**

**For return, please check the return policy with  
the retailer or market place you bought from.**

**Appreciate your purchasing from us.  
Pop up your life by our furniture piece!**

## OWNER MANUAL



---

### NOTE:

This brochure contains IMPORTANT safety info. Please read and keep for future reference.

---

# MAINTAINANCE AND WARNING

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives, spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.




Weight Limitation

**300LBS**


# PARTS LIST

A\*1



Frame

B\*1




Top cover

Persons Required For Assembly :




## STEP 1




Install the top cover on the base frame.

## STEP 2




After installation, adjust the adjustable level to maintain balance.

## Remark 1



When the top cover is placed normally, it can be used as a footstool. It can also be rotated 180° to be as a coffee table.

## Remark 2



We can unstick the Velcro on the bottom frame and the top cover, remove the outer fabric, and wash it.