


















ASSEMBLY INSTRUCTIONS

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment. (Note: Loosely thread all screws/bolts first. Once the item is assembled then completely tighten.)

PARTS LIST:				HARDWARE LIST				
NO.	Description	Sketch	Quantity	NO.	Sketch	Description	Size	Quantity
A	Top		1	F		Blots	Ø1/4"*5/8"	8
B	Legs		4	G		Flat washer	Ø1/4"	16
C	Center Leg		1	H		Lock washer	Ø1/4"*3/4"	16
D	Shelf		2	K		Allen wrench	M4*65L	1
E	Floor		2	L		Hex nut	M4	8
				M		Wrench	M8	1
				N		Screw wood	1/2"L	8
				Y		Blots	Ø1/4"*2-2/8"	2



Adjustable leveler