


# ASSEMBLY INSTRUCTIONS



*Fine Furniture for every stage of life*

# ASSEMBLY INSTRUCTIONS

## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 10 MINUTES

## PARTS IDENTIFICATION

### B1(BOX 1)

A SEAT AND BACK



1PC

### B2(BOX 2)

B FRONT LEG



2PCS

C RIGHT BACK LEG



1PC

D LEFT BACK LEG



1PC

## Z

## HARDWARE IDENTIFICATION

1 BOLTS M8\*16



12PCS

2 SPRING WASHER Ø13



12PCS

3 FLAT WASHER Ø6\*16



12PCS

4 ALLEN WRENCH 5MM



1PC


### NOTE:

Quantities shown are for one chair.

Hardware pack is located in 190745B2

# ASSEMBLY INSTRUCTIONS

## STEP1



## STEP2

