










3.5M




A  ×1	C  ×1		
B  ×1	D  ×4		
E  ×1	F  ×1	J  ×1	
P  ×1	G  ×1		
I  ×1	H  ×1		
M  ×2	N  ×3	O  ×1	L  ×1
Q  ×1	R  ×2	S  ×1	T  ×1

Scanned with CamScanner


①




②




③




④



Scanned with CamScanner



⑤
N
J
J
R
R
⑥
E
C
D
L
A
B
⑦
S
T
F
C
H
C
F
⑧
P
P

9 Release Umbrella Ribs Before Open




IMPORTANT: Before opening your frame,be sure the arms are not tangled. Gently separate the arms if they are locked together.

10




11




360° Rotation Function

12




Scanned with CamScanner

13




Scanned with CamScanner

2-height adjustment funtions



3 different ways for mounting bases, screws and marble bases not included.



Scanned with CamScanner