

# BFTLPT-1017



# EASY TO CARRY

## HOWTO USE



1. Open the cap of water holding tank, fill the fresh water



2. Press the button and pull out slide valve at the same time, then open the seat cover before use



3. Close the seat cover, pull up and press down piston pump one or more times to rinse thoroughly by water after use



4. Close the slide valve by pushing fully for next use  
Bottom innovative auxiliary drag wheel design

# EASY TO CLEAN

## HOW TO CLEAN



1. Keep the slide valve and seat cover closed

When the indicator changes from green to red, it indicates that the Sewage tank needs to be cleaned



2. Press the detached button to separate the water holding tank and sewage tank



3. Rotating the waste pipe, then remove cap and pour sewage



4. Rinse repeatedly after add fresh water or detergent, then pour