




ROCKING BISTRO SET INSTRUCTION MANUAL



ABRKC171WH
| ABRKC194GR
ACRKC195WH






**We stand behind our brand. If you're not satisfied with your purchase, reach out to get a replacement or refund.
Contact us to save time and money**

 : **ea-aftersale@outlook.com**



PARTS LIST

1

Parts	pcs	Accessories
A	1	
B	2	
C	1	
D	1	
I	2	
J	2	
K	2	
L	2	
M	2	




PARTS LIST


2

Parts	pcs	Accessories
N	2	
O	2	
E	8	 M6x15MM
F	4	 M6x30MM
P	12	 M6x40MM
Q	4	 M6x50MM
G	28	
H	1	


01

STEP





02**STEP**

ASSEMBLE




ASSEMBLE




03**STEP****P****2PCS****Q****2PCS****G****4PCS**

04


STEP



ASSEMBLE



ASSEMBLE



CONTACT US !

Do Not Return

Our friendly team is here to help -just reach out!



ea-aftersale@outlook.com



Send Message

If you have any questions, please leave the order No. and related picture information
we will reply you within 24 hours, and solve the problem, ASAP!