


ASSEMBLY INSTRUCTIONS

1. Assemble the lighting fixtures according to 1-10 instruction.
2. Assemble the canopy on the ceiling.

03-00859



CAUTION

1. For indoor use only.
2. Keep out of reach of children and animals.
3. Use 120V~60Hz only, use MAX40 watts, E26 bulb only.
4. Do not use in the bathroom or damp places.
5. Place the lamp on a flat surface and ensure there are no flammable materials around it.
6. Before cleaning the lamp, ensure it is switched off.
7. Before replacing the bulb, ensure the plug has been put out from socket and the lamp has cooled down.
8. Do not pull the plug out of the socket with wet hands.
9. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.