



Assembly Instructions














Thank you for purchasing our product!


Give us a chance to make it right.

Do not return this item. Contact our friendly customer service department with any problems or comments.




We appreciate your business!


1x1 	2x4 	3x2 	4x2 	5x2 	6x2 
Table Top Panel	Table Leg	Chair Left Side Panel	Chair Right Side Panel	Chair Seat Panel	Chair Bottom Rail
7x2 	Ax8 	Bx4 	Cx4 	Dx12 	
Chair Back Rail	Long Bolt	Wood Dowel	Short Screw	Screw	




On a soft, clean surface, turn the Table Top Panel (1), attached Table Leg (2) to Table Top Panel (1) by using Long Bolt (A) as shown.



Assembly Chair Left Side Panel (3), Chair Right Side Panel (4), Chair Seat Panel (5), Chair Bottom Rail (6) by using Screw (D) and Wood Dowel (B) as shown.



Attached Chair Back Rail (7) to Assembly Unit by Short Screw (C).



WARNING:

DO NOT STAND ON THE CHAIR. DO NOT USE THIS CHAIR AS A STEP LADDER.
 USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
 DO NOT USE THIS CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.
 AT LEAST EVERY 4 MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.
 IF PARTS ARE MISSING, BROKE, DAMAGED OR WORN, STOP USING THIS PRODUCT UNTIL YOU HAVE REPAIRED IT FULLY.
 FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.
 PLEASE DO NOT USE KNIFE TO OPEN ANY PARTS OF THE BOX OR CHAIR.