


INSTALLATION MANUAL





* Guests need to prepare their own :




Phillips screwdriver




PARTS







1 X1




2 X1



3 X1




4 X1




5 X1




6 X1




7 X1




8 X1




9 X1




10 X1



11 X1




12 X1




35mm

A X18+2



Ø6 X 30mm

B X12+2



Ø15 X 9.5mm

C X18+2




Ø3.5X10mm

D X12+4



Ø4X14

E X1




F X1



Ø5 X 30mm

G X4




Ø20


H X18+2



I X6




K X1




Ø3X15mm

L X6




L=300mm

CL X1




L=300mm

CR X1



L=300mm

DL X1





L=300mm

DR X1

1


D		X6
CL		X1
CR		X1




2




A		X6
---	---	----

B		X4
---	---	----





A		X4
B		X4

3





C		X4
---	---	----

4




C		X6
---	---	----

5






6




- 7 -



A		X4
B		X4
C		X4




L		X6
J		X6




G		X4
K		X1





A		X4
---	---	----



C		X4
---	---	----



D		X4
DL		X1
DR		X1
E		X1
F		X1
H		X8




WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS** install Anti-tip device provided.
- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on any drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

***This is a permanent label.
Do not remove!***



SAFETY FIRST, STYLE ALWAYS

Thank you for choosing our products. To ensure safety and performance, please follow these instructions:

- **Assembly:** Carefully follow instructions and tighten all parts.
- **Intended Use:** Use furniture as intended and adhere to weight limits.
- **Handling:** Move gently and check for loose parts regularly.
- **Tipping:** Tall or unstable furniture may tip over if not secured, especially in homes with children or pets.
- **Overloading:** Exceeding weight limits can lead to collapse or damage.
- **Sharp Edges:** Handle furniture with sharp corners carefully, especially around children.

MAINTENANCE & CLEANING TIPS

- **Regular Cleaning:** Use a soft, dry cloth to wipe the surface of cabinet regularly. Avoid harsh chemical cleaners.
- **Protect from Sunlight:** Keep cabinet out of direct sunlight to prevent damage to the material and finish.

DON'T WORRY, WE'VE GOT YOUR BACK.

We don't just sell furniture — we're here for the long haul! If you run into any issues due to manufacturing defects or material problems, we offer a 1-year warranty. That means we'll replace any faulty parts for free — no hassle.