


ASSEMBLY INSTRUCTION



TV Cabinet

CATALOGUE

Precautions	01
Parts List	02-03
Hardware List	04
Tool List	05
Assembly Process	06-37

INTRODUCTION

Thank you for purchasing our products. Please read the instructions carefully before installation and keep it in a safe place for future reference. If you need any assistance or support, please feel free to contact our customer support team.

PRECAUTIONS

This package contains numerous components and hardware pieces. Please identify and verify all parts against the parts list before you begin assembly.

WARNING: Choking Hazard. This product contains small items. Keep all parts and hardware out of the reach of children during assembly.

To prevent scratches, assemble the product on a soft, non-abrasive surface such as a carpet, blanket, or the flattened cardboard packaging.

Some components are heavy. For safety, we recommend this product be assembled by two adults.











The unit may be unstable until assembly is fully complete. Do not move the product until all steps are finished.










If you encounter any issues or have questions, please contact our customer service team for assistance.

- * Please be sure to follow the installation steps in the manual to avoid unnecessary losses caused by improper installation.
- * If you need further assistance, please contact the customer service online.







After-Sales Service Hotline: (800)661-5928

Parts List




ID	Parts	QTY
1		1
2		1
3		1
4		1
5		1
6		1
7		4
8		1
9		1
10		1




ID	Parts	QTY
11		2
12		1
13		1
14		2
15		1
16		2
17		1
18		1
19		1
20		2

Parts List


ID	Parts	QTY
21		4
22		4
23		4
24		4
25		2
26		1

Hardware List


ID	Parts	QTY
A		43+2
B		43+2
C	 8*30mm	20+1
D	 5*45mm	8
E	 4*60mm	16
F	 L200mm	4 sets
G	 3*12mm	48+2
H	 6*76mm	8
I		4
J		2

ID	Parts	QTY
K	 3.5*12mm	2
L		4
M	 3.5*12mm	24
N		2
O	 4*32mm	18
P	 4*25mm	4
Q		20
R	 3*19mm	20


Tool List

ID	Parts	QTY
Z1	 4mm	1
Z2		1


Required Tools (Not Included)




 **Wall mounting only**
These tools are not required for product assembly.






Multi-person installation







STEP 1


**A** X8

Install the screw
correctly to secure
the screw.


STEP 2




STEP 3






STEP 4

 **E** X8







STEP 5

**F** X2**G** X12



△ Pay attention to the position of the screws

STEP 6

**F** X2**G** X12




△ Pay attention to the position of the screws

STEP 7

**A** X6

Install the screw
correctly to secure
the screw.



STEP 8

**B** X4



STEP 9



B X2





STEP 10

**B** X4




STEP 11



B X4





STEP 12



 **Do not use this tool for installation.**


STEP 13

 **H** X8




 **Do not use this tool for installation.**


STEP 14




STEP 15





STEP 16

 **A** X13



 **J** X2

 **K** X2





Install the screw
correctly to secure
the screw.



STEP 17

**C** X12

STEP 18

**B** X13

STEP 19

**Q** X20**R** X20


STEP 20

Wall-Mounted Installation

Step 1: Identify the correct location for the anti-tipping device on the wall and make a clear mark.

Step 2: Drill a hole, then fix the expansion plug firmly in the wall.




Step 3: Use screws to attach the L-shaped angle bracket to the wall.





N X2



O X2





STEP 21

**L** X4**M** X8




STEP 22



M X16






STEP 23






STEP 24



G X24





STEP 25

**A** X16

Install the screw
correctly to secure
the screw.

STEP 26






STEP 27



STEP 28



B X16




STEP 29




The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.




When door is crooked




Please take the following steps to adjust first.

- 1 Rotate the "front and rear screws" to the left




* After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.


- 2 Push the door to the cabinet



- 3 Rotate the "front and rear screws" to the right



When 2 doors are not tight




* If the 2 doors are overlap, please turn the "internal & external screw" to the left.

1

Turn "internal & external screw" to the right can make the door approach inside. Please adjust the doors little by little.


The left door

Top




Turn right

Bottom




Turn right




The right door

Top




Turn right



Bottom



Turn right




when door is leaning



1



Turn "internal & external screw" to the left can make the top of the door tilted outward.

Top



Turn left


Bottom



1



Turn "internal & external screw" to the left can make the bottom of the door tilted outward.

Top




Turn left


Bottom




When door is higher
on top




1 Turn "up & down screw" to the left.



2 Lower the door's height so that
2 doors are of the same height.



3 Turn "up & down screw" to the right.





After-Sales Service Hotline: (800) 661-5928
Support Hours: Mon-Fri, 9:00 am - 5:00 pm PST/PDT