

# **ASSEMBLY INSTRUCTION**


## ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.












### Warning !













1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME PER UNIT: 50 MINUTES

## PARTS IDENTIFICATION


A	TOP PANEL		1PC	F	LEFT SIDE PANEL		1PC
B	BOTTOM PANEL		1PC	G	RIGHT SIDE PANEL		1PC
C	BASE PANEL		1PC	H	BACK PANEL		1PC
D	DIVIDER PANEL		2PCS	I	SWIVEL PLATE		1PC
E	SHELF		2PCS				

Z	HARDWARE PACKAGE						
1	LARGE BOLT		8PCS	7	SCREW		6PCS
2	MEDIUM BOLT		4PCS	8	FLAT WASHER		16PCS
3	SMALL BOLT		4PCS	9	GLUE		1PC
4	CAM-BOLT		14PCS	10	COVER		14PCS
5	CAM-LOCK		14PCS	11	SHELF SUPPORT		8PCS
6	HOOK		3PCS	12	ALLEN WRENCH		1PC


STEP 1




STEP 2




STEP 3




## STEP 4



## STEP 5



STEP 6



STEP 7

