


# ASSEMBLY INSTRUCTION



Model: Savoy Run 1.4m











## PRE-ASSEMBLY PREPARATION:

Notice:

1. This chicken house is for outdoor use only.
2. Warning fire hazard: keep away from naked flame.
3. Do not place heavy items on this chicken house, this may result in damage.
4. Assemble this chicken house on a flat surface.
5. An appropriate screwdriver is to be used in the assembly of this chicken house.


# ASSEMBLY INSTRUCTION


## PARTS LIST:

<p>A×1</p>  <p>Left side board</p>	<p>B×1</p>  <p>Right side board</p>	<p>C×1</p>  <p>Upper back board</p>	<p>D×1</p>  <p>Lower back board</p>	<p>E×1</p>  <p>Upper front board</p>
<p>F×1</p>  <p>Lower front board</p>	<p>G×1</p>  <p>Left-side roof board</p>	<p>H×1</p>  <p>Right-side roof board</p>	<p>SCREWS : ①  Ø3.5 x 40 22Pcs                  ②  Ø3.5 x 50 8Pcs</p>	


## STEP-BY-STEP ASSEMBLY:


### STEP 1




①  Ø3.5 x 40 10Pcs


### STEP 2



①  Ø3.5 x 40 12Pcs

### STEP 3




②  Ø3.5 x 50 4Pcs


# ASSEMBLY INSTRUCTION


OPTIONAL:

STEP 1



STEP 2



②  Ø3.5 x 50 4pcs