


ASSEMBLY INSTRUCTIONS

Important Safety Instructions:

- Please read all instructions before beginning assembly
- Please make sure receive all the parcels to start the assembly
- For your safety and convenience, assembly by two people is recommended
- Use the parts and hardware lists to identify and separate each of the components included
- Save all packing materials until assembly is completed to avoid the accidental discarding of smaller parts or hardware
- Use of power tools is not recommended



THANK YOU FOR PURCHASING

PARTS LIST

1 X1

2 X1

3 X1

4 X1

5 X1

6 X2

7 X2

8 X1

9 X2

10 X2

11 X2

12 X1


13 X1

14 X1








15 X2






16 X1

17 X1





HARDWARE LIST

Name	Part	Qty.	Spare
A		12	1
B		12	1
C		16	1
D		2	
E		2	
F		3	
G	 M4 x 12mm	6	1
H		2	
I		1	
J		1	
K	 2" Screw	4	
L	 1-1/2" Screw	12	
M	 9/16" Screw	12	
N	 1/2" Screw	28	1

Name	Part	Qty.	Spare
O		36	2
P		8	
Q		4	
R		4	
S		2	
T	 1-1/2" Screw	2	
U		1	

STEP 1









A x 12pcs 

N x 16pcs 

C x 12pcs 



D x 2pcs 

E x 2pcs 





STEP 2

C x 4pcs





STEP 3

T x 2pcs





STEP 4

B x 4pcs





STEP 5

B x 4pcs





STEP 6

K x 4pcs



STEP 7


B x 4pcs






STEP 8

Peel off the adhesive sticker's protective paper and bond it onto the designated position before secure with nails.

○ x12pcs 

Q x4pcs 


U 






STEP 9

Peel off the adhesive sticker's protective paper and bond it onto the designated position before secure with nails.

○ x12pcs 

P x4pcs 


U 





STEP 10

Peel off the adhesive sticker's protective paper and bond it onto the designated position before secure with nails.


O x12pcs 


P x4pcs 


U 




STEP 11

M x12pcs 

R x4pcs 


S x2pcs 

Do not use power tools
for Drawer Bracket




STEP 12


N x4pcs



L x4pcs



Do not use power tools
for Drawer Bracket





STEP 13

F x1pc




G x2pcs




STEP 14


H x2pcs



I x1pc




J x1pc




STEP 15


N x8pcs



L x8pcs



Do not use power tools
for Drawer Bracket






STEP 16

F x2pcs




G x4pcs




STEP 17


STEP 1.



STEP 2.



STEP 3.




- Move unit to final location.
- Adjust drawer fronts as shown below.


Step1--Loosen screws on back of drawer front brackets as shown.

Step2--Position drawer front as required.

Step3--Tighten screws while holding drawer front in position.



Maximum weight capacities



Furniture Care & Cleaning Instructions

- Do not expose the furniture to strong sunlight, which causes discoloration and shorten the product lifetime.
- Do not expose the furniture to extreme heat, cold, or humidity, which may cause wood to swell or warp.
- Do not leave the furniture wet with beads of water standing on the furniture.
- Wipe spills with a clean dry cloth. Do not use chemicals or abrasives for cleaning!
- **TAKE NOTE: THE BOLTS MAY SLIGHTLY LOOSEN OVER TIME. IF YOUR FURNITURE FEELS "WOBBLY" OR LOOSE, PLEASE RE-TIGHTEN BOLTS.**

Wood Furniture Care & Cleaning Instructions

To maintain the quality of your wood furniture, do not expose it to direct sunlight or excessive temperatures; extreme changes in humidity can cause warping. Always use coasters, pads, cloth or felt to protect the furniture surface. Use protective mats under hot dishes. Use a protective pad when writing with a pen. Lift objects rather than dragging them over the furniture surface. Blot spills immediately with a clean cloth. Dust often using a soft, clean, lint-free cloth. Avoid harsh fabrics, paper towels or disposable dusting towels as they may scratch the surface. Use a non-silicone and non-wax polish; do not use soap, water or wax.

FURNITURE WARRANTIES

90 days warranty on all of our Indoor furniture from date of delivery against manufacturer defects and structural failure under normal use and conditions; 90 days warranty from date of delivery against damage of parts. Parts will be replaced, repaired or refinished in the original color and style, if available; a similar color and style will be offered if the original has been discontinued.

IMPORTANT LIMITATIONS

Please note that our warranties do not cover failure due to any repairs or modifications to the product after purchase, accidental damage, abuse, misuse, commercial use, or normal wear and tear, including: fading, scratched or chipped finishes, weathering under normal weather conditions, staining or discoloration. The term "lifetime" as used in this statement of warranties shall mean a period of no longer than 30 days from the date of delivery of any item covered by a 90 days warranty . The limited warranties described above are extended to the original purchaser of the product only.

Any defects or missing parts must be reported within the 1st 30 days of receipt of the merchandise.