


Assembly Instructions

For more information contact our team: service.ec@foagroup.com

WI4373C



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench




(Included)

Phillips Screwdriver



(Not Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#1 x 2pcs
Side Frame



#2 x 1pc
Back Metal frame



#3 x 1pc
Front Metal frame



#4 x 1pc
Top shelf



#5 x 1pc
Bottom shelf



#6 x 2pcs
Lock Caster



#7 x 2pcs
Caster

Hardware List




#A x 8pcs
Flat Washer



#B x 8pcs
Small Lock Washer



#C x 4pcs
Large Lock Washer



#D x 8pcs
Bolt 1/4" X 13/16"



#E x 8pcs
Acorn Nut M6



#F x 1pc
Open Ended Wrench M6




#G x 1pc
Open Ended Wrench M10



#H x 12pcs
Screw Ø8 x 16mm





Exploded View



Align front metal frame (#3) to the holes of the side frame (#1). Insert bolts (#D) to the holes of the side frame (#1) and front metal frame (#3). Secure by using flat washer (#A), lock washer (#B), then hex nut (#E) onto bolts (#D).

#A x 2pcs
#B x 2pcs
#D x 2pcs
#E x 2pcs





#A x 2pcs
#B x 2pcs
#D x 2pcs
#E x 2pcs

#D


#2

Align back metal frame (#2) to the holes of the side frame (#1). Insert bolts (#D) to the holes of the side frame (#1) and front metal frame (#3). Secure by using flat washer (#A), lock washer (#B), then hex nut (#E) onto bolts (#D).



Align side frame (#1) to the holes of the metal frame (#2,3). Insert bolts (#D) to the holes of the side frame (#1) and metal frame (#2,3). Secure by using flat washer (#A), lock washer (#B), then hex nut (#E) onto bolts (#D).

#A x 4pcs
#B x 4pcs
#D x 4pcs
#E x 4pcs



#D

#A

#B


#E

#F


#1




#H x 6pcs




Align bottom shelf (#5) to the holes of the metal frame.
Secure by using screws (#H).



#H x 6pcs




Align top shelf (#4) to the holes of the metal frame. Secure by using screws (#H).





#C x 4pcs

Attach large lock washer (#C) to the wheels (#6,7), then secure wheels (#6,7) onto the metal legs.



ASSEMBLY COMPLETED

