




Owner Manual





ASSEMBLED BY 2 ADULTS




IMPORTANT INFORMATION!

Please read the instruction manual, before installing the product.





AVOID SCRATCHES!

To avoid scratching the wood panel, you can put carpet on the floor before installation.



INSTALLATION TIPS !

Two people together will be faster to install.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, please purchase the wall attachment that fit your wall. Please read and follow each step of the instructions carefully.

NOTE !


Assembled product should be re-tightened every 3 months - in order to long-term use.

Please clean the product regularly with a rag dipped in a neutral cleaner to keep it clean and tidy.












Pay attention, the screws may loosen during use.




























Please prepare the following tools




Please confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size.


A x 51 +1	B x 51 +1	C x 45 +1	D x 2	E x 22 +1
 Ø 6 x 35mm	 Ø 15 x 10mm	 Ø 6 x 30mm	 Ø 3 x 16mm	 Ø 3.5 x 14mm
F x 8	G x 36 +1	H x 9 +1	I x 4	J x 4
	 Ø 3 x 12mm	 Ø 4 X 35mm		
K x 4 +1	L x 2	M x 4 +1	N x 20 +1	O x 4 +1
 Ø 4 x 18mm		 Ø 4 X 50mm	 Ø 4 X 60mm	 Ø 6 x 50mm
P x 8	Q x 2	R x 4 +1	S x 20	T x 2
		 Ø 3 X 12mm		
U x 1				
				




①  1PC	②  1PC	③  1PC	④  1PC
⑤  1PC	⑥  1PC	⑦  1PC	⑧  2PCS
⑨  1PC	⑩  1PC	⑪  2PCS	⑫  1PC
⑬  2PCS	⑭  6PCS	⑮  4PCS	⑯  2PCS
⑰  1PC	⑱  1PC	⑲  1PC	⑳  1PC
4/24			

21  1PC	22  1PC	23  1PC	24  1PC
25  1PC	26  1PC	27  3PCS	28  6PCS
29  1PC			





1

A x 4

 Ø6 x 35mm






2

A x 6

 Ø6 x 35mm

F x 4


G x 8

 Ø3 x 12mm



3

B x 6






Ø15 x 10mm

C x 4



Ø6 x 30mm






4

B x 4




Ø15 x 10mm






5

A x 12



Ø6 x 35mm



6

B x 6






Ø15 x 10mm


C x 6





Ø6 x 30mm







7

C x 7  $\varnothing 6 \times 30\text{mm}$	N x 10  $\varnothing 4 \times 60\text{mm}$	
---	--	---



8

A x 4  $\varnothing 6 \times 35\text{mm}$	D x 1  $\varnothing 3 \times 16\text{mm}$	
---	---	---



9

B x 4






Ø15 x 10mm

C x 4




Ø6 x 30mm






10


A x 4







Ø6 x 35mm




11





12





13

G x 2  $\varnothing 3 \times 12\text{mm}$	I x 2 	J x 2 	K x 2  $\varnothing 4 \times 18\text{mm}$	
---	---	---	---	---








14




G x 8  $\varnothing 3 \times 12\text{mm}$	
---	---




15



16





17

A x 6

 Ø6 x 35mm

F x 4


G x 8

 Ø3 x 12mm





18

B x 6

 Ø15 x 10mm

C x 4

 Ø6 x 30mm





19

M x 4



Ø4 x 50mm



20

B x 6






Ø15 x 10mm

C x 2



Ø6 x 30mm



21

B x 6






Ø15 x 10mm

C x 6



Ø6 x 30mm



22

C x 7






Ø6 x 30mm

N x 10




Ø4 x 60mm






23

A x 4



Ø6 x 35mm



24

B x 4






Ø15 x 10mm


C x 4



Ø6 x 30mm



25






26

B x 4



Ø 15 x 10mm



27

G x 2



Ø3 x 12mm

I x 2






J x 2



K x 2



Ø4 x 18mm






28


G x 8



Ø3 x 12mm






29



Ø6 x 35mm

Ø15 x 10mm

Ø6 x 30mm





31

H x 5



Ø4 x 35mm



32



Q x 2




R x 4




Ø3 x 12mm





33






34

E x 20  Ø 3.5 x 14mm	S x 20 	
---	---	--



35

T x 2



WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly.
- Please leave your purchase order number, along with some details of the problem. If you want a replacement part, please circle the part you need on the instruction, we will reship it soon. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided.
- For non-quality returns, customers may be required to pay return shipping costs. Please ensure the goods are intact and tidy when returning.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.