



ASSEMBLY INSTRUCTION
Item : N715P503381N
RECT DINING TABLE



ASSEMBLY INSTRUCTION
Item : N715P503381N






ASSEMBLY INSTRUCTION

Item : N715P503381N

PART LIST

N715P503381N

1  Top panel A - 1pc	2  Top panel B - 1pc	3  Top panel C - 1pc	4  Up side bottom rail - 2pcs
5  Link bar - 2pcs	6  Front side panel A - 2pcs	7  Front side panel B - 2pcs	8  Left-right side panel - 2pcs
9  legs - 4pcs			


ASSEMBLY INSTRUCTION
Item : N715P503381N
HARDWARE LIST

N715P503381N			
A  Ø1/4"32mm Bolt (28pcs)	B  Ø1/4 Spring washer (28pcs)	C  Ø1/4"16"1.2mm Flat washer (28pcs)	D  Ø5/16" x 80mm Threaded shaft (8pcs)
E  ØØ5/16" Spring washer (8pcs)	F  ØØ5/16" (42"20"12mm) Semicircle (8pcs)	G  Ø5/16" Nuts (8pcs)	H  Ø8"30mm Wood dowel (16pcs)
I  Allen wrench (1pc)	J  Wrench (1pc)		


ASSEMBLY INSTRUCTION

Item : N715P503381N

Step 1





Step 2



ASSEMBLY INSTRUCTION

Item : N715P503381N



Step 3



			
Ø1/4"32mm	Ø1/4"32mm	Ø1/4"16"1.2mm	Allen wrench
A X 12	B X 12	C X 12	I X 1

Step 4

x4





Ø5/16" x 80mm
D X 8

ASSEMBLY INSTRUCTION


Item : N715P503381N

Step 5



Step 6

x2




			
O5/16"	O5/16" (42*20*12mm)	O5/16"	Wrench
E X 4	F X 4	G X 4	J X 1


ASSEMBLY INSTRUCTION

Item : N715P503381N

Step 7



Step 8




			
Ø5/16"	Ø5/16" (42*28*12mm)	Ø5/16"	Wrench
EX 2	FX 2	GX 2	JX 1


ASSEMBLY INSTRUCTION

Item : N715P503381N

Step 9



Step 10




			
Ø5/16"	Ø5/16" (42*20*12mm)	Ø5/16"	Wrench
EX 2	FX 2	GX 2	JX 1


ASSEMBLY INSTRUCTION

Item : N715P503381N

Step 11




Step 12




ASSEMBLY INSTRUCTION

Item : N715P503381N

Step 11



Step 12



			
Ø1/4"×32mm A X 16	Ø1/4"×32mm B X 16	Ø1/4"×16"×1.2mm C X 16	Allen wrench 1 X 1

ASSEMBLY INSTRUCTION

Item : N715P503381N

Step 13

