






















Assembly Instructions

Parts required

 Ax1	 Bx1	 Cx1	 Dx2
 Ex1	 Fx1	 Gx1	 Hx1
 Ix1	 ① 8+1PCS	 ② 3PCS	 ③ 32+3PCS
 ④ 4PCS	 ⑤ 2PCS	 ⑥ 8+1PCS	 ⑦ 4PCS
 ⑧ 1PC	 ⑨ 2PCS	 ⑩ 2PCS	 ⑪ 8+1PCS

STEP 1



③ ③
② ② → A

③
② → F


⚠ Magnet outward.

Φ3X15MM
③x6

②x3

STEP 2

Note: Tighten All bolt #1 to 95% first. After completing Step 4, tighten All bolt completely.




→ B ← C

→ F

Φ6X35MM
①x4 ⑥x4

STEP 3



D

E

D


⑦x4

Φ6X35MM
①x4

⑥x4

STEP 4

Note: When every parts is OK, You can tighten all bolts #1 in this step;




→ A

⑦ ⑦ ⑦ ⑦

STEP 5




STEP 6




STEP 7

Note: The left door is #H, the right door is #I.



STEP 8



STEP 9



ATTENTION

If there is any missing, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions. Please also provide us your full address so we can send replacement to you as soon as possible

We are concerned about each customer's experience, if there is any loss or damage, please contact us at any time, we will provide effective solutions.

Please attach your Order ID so that we can assist you better.