Instruction Manual
Please save this manual for future reference.

Product Name:	S/3 Pre-lit Artificial Christmas Trees

Thank you for purchasing this product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.
Unpack all parts from Styrofoam and bubble wrap inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product.


CARTON CONTENTS:

Description	Quantity		Description	Quantity
Tree Top (A1)	1		Tree Top(C1)	1
Middle Tree Section(A2)	1		Middle Tree Section (C2)	1
Small Tree Base (A3)	1		Large Tree Base (C3)	1
Tree Top (B1)	1		Battery Box（3 AA）	2
Middle Tree Section(B2)	1		Battery Box（6 AA）	1
Medium Tree Base(B3）	1			

Before You Start
1. Decide on an appropriate location for your product, please read assembly and Instruction procedure carefully. Note: This tree may utilize light sets that are marked for indoor and outdoor use, but the artificial tree is for indoor display only.
2. Retain the instructions for future use and save the carton for storing your tree.

Assembly and Instruction Procedure (no tools required for assembly):
Remove all packaging (i.e., cardboard or plastic) before beginning. If your artificial tree has snow-flocking, we suggest unpacking the tree on a large cloth. Some of the flocking may come off during unpacking and fluffing of branches.

1. Assemble the Tree:
The light strings on each tree are pre-connected. Simply insert and secure the tree sections tightly of each size as shown in the illustration. After trees are fully assembled, follow the battery box instructions below to light up for decoration.



2FT 3FT 4FT

Instruction Manual
Please save this manual for future reference.

Product Name:	S/3 Pre-lit Artificial Christmas Trees

2. Shape the Tree:
Begin to shape the branches from the bottom of the tree to the top. Start with the tree tips farthest away from the center pole.After shaping the tree, step back to look for any gaps. Reshape branches as needed. You can upsweep the branch tips for uniform look. Once you have the tree the way you want it, you can start decorating!



Fig.1


Fig.2


Fig.3

BATTERY BOX INSTRUCTIONS:
- To insert batteries, open the battery box cover.
- Insert 3 x AA batteries into each battery box of 2FT & 3 FT tree, and 6 x AA batteries into the battery box of 4FT tree, you will need 12 AA batteries in total.**(Batteries not included)**
  - **Batteries are to be inserted with the correct polarity.**
  - Do not mix alkaline, standard, or rechargeable batteries.
- Close the battery box.

By pressing the button on the battery box, you can achieve the following function:
-- Two gears with timber: TIMER ON - OFF
(Timer: 6h ON, 18h OFF, automatic.**)**



Storage Tips:
- Remove batteries from battery compartment when not in use.
- Store the product in a cool, dry location protected from sunlight where the temperature does not exceed 35˚C (95˚F).

WARNINGS:
- This product is for indoor decorative use only.
- Carefully remove from packaging, retain the box for storage and future reference.
- To avoid risk of suffocation to animals or children, dispose of the plastic bag immediately.
- This is not a toy. Keep children and pets away from the product.
- Choose a suitable location and ensure the products do not cause an obstruction or a potential hazard.
- Position on a flat level surface.
- Do not illuminate while the product is still within its packaging.
- Do not connect the item electronically to any other item.
- Do not leave the product operating unattended.
- Do not allow any plastic parts to come into contact with heat or flames or submerge in water.
- The supply terminals are not to be short-circuited.
- **Important:** bulbs are not replaceable.
- Color reproduction is accurate within the limitations of the manufacturing process. Also note, colors will vary under different lighting.