


# Operating Instructions

## Whirlpool




The Whirlpool is equipped with an ON/OFF Button (fill tub until the highest jet is covered by at least 2" of water. Do not run pump without water in the tub.)

1. Press the Button to start the pump.
2. Press a second time to stop the pump. The Control Box is manufactured with a 20 minute timer that will turn off the unit automatically. To continue your bath, simply push the Button to repeat cycle.

**Note:** Tub equipped with built in water level sensor, please make sure to fill the tub with water until the water level sensor stud is covered. Now you can press the Button to start the pump.

## Air System



The Air System is equipped with an ON/OFF Button (fill tub until the highest jet is covered by at least 2" of water. Do not run Blower without water in the tub.)

1. Press ON/OFF key once to start the Blower in Constant mode. Press a second time to turn the motor off. A built-in timer shuts motor off after 20 minutes, unless manually turned off first.
2. Successive presses of Pulse/Wave Mode key while Blower is on changes its mode from Constant mode to Wave Mode and back to Constant mode. Constant mode: The Blower is on without variation of speed. Wave mode: Blower speed varies from High to Low and vice versa.
3. Press and hold the Up Arrow key while Blower runs in Constant mode to increase its speed.
4. Press and hold the Down Arrow key while Blower runs in Constant mode to decrease its speed.