ASSEMBLY INSTRUCTION

N-000-C-1640



Trouble shooting:

Missing / Wrong / Broken parts and installation issues



Send email with your question, pic and order NO.to rhr8nxede@sina.com



Respond within 24 hours



Issue resolved

EN

Thank you for purchase on our products, please contact us if you have difficulty withassembly or need replacement parts. 24-hour customer service will be available to help you at any time.

You can contact the platform's email address and please include your username ororder ID so that we can better assist you.

WARNING

Serious or fatal injury may occur from unexpected assembly or use.

- 1. During the assembly process, keep all parts away from babies or children.
- 2. Always securely fix this product to the wall. Make sure the wall area to be drilled is free from hidden electrical wires, water and gas pipes.
- 3. Use of tip-over restraints may only reduce, but not eliminate the risk of tip over
- 4. Unless specially designed to accommodate, do not set heavy objects on top of this product.
- 5. Place the heaviest items on the lowest shelf.
- 6. Never allow children to climb or bang on drawers, doors or shelves.

Important Tipsand Maintenance





1.
Keep children and animals away from working area as smaller parts may cause choking if swallowed.




Never place liquids or anything damp upon furniture as it will mark. Ensure a coaster or running is beneath.



3.


Never use ammonia based cleaning products as it will damage the finish.




To avoid fading, keep furniture out of direct sunlight.



5. Use a soft cloth (dry cloth) when wiping or cleaning surfaces.



6.
Two person are required.
Please two or more person for assembly this unit.




/.
Lay a soft matt down to protect the furniture piece before and during assembly.

Before Assembly


Tips Before Your Start:

- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children




Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.

CAM LOCK




When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.

Quickfit head should be in the centre of the cam lock when the two panels are joined.
Cam lock should be inserted before quickfit.





Turn cam lock clockwise to tighten.


Hardware List Please check you have all the fittings part or tools are listed in below.





Component Panels & Part List Please check you have all the panels are listed below.






















STEP 13 **(G)** E \bigcirc 3 1рс STEP 14 **D** 12 $^{\odot}$ 2pcs




















4pcs

