




FREDDO

Emoji Rider User Manual

SKU No.:FR1111




PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING AND KEEP IT FOR FUTURE USE.

Product name:Emoji Rider SKU No:FR1111 Dimension: 23.6x6.7x12.2 inch

Suitable age: with saddle 2-3 years (3 years not included),
Scooter : 3 years and above

Maximum load: with saddle 25 kgs/55lbs, Scooter 50kgs/110lbs

Product Overview




How to Use

While holding the handlebar, place one foot on the scooter while the other foot kicks on the ground to move the scooter forward. Tilt the scooter to change the direction you're going, and step on the brake to stop.

Place of Use


The scooter should be used in parks, neighbourhoods, and flat and open roads. Do not use it on roads with traffic, crowded or sloped locations.

Installation Steps




Open the package, and check if any spare parts are missing or damaged.

— Changing the Front Cap




This product is designed so the user can change the front cap or pattern to the one they like..

—Front cover replacement




- 1.Press the spring lock (location as shown in Picture #2).
- 2.Change the front cap after it pops out.

— Unfold and Lengthen




- 1.Lift up the handlebar to lock automatically until you hear the click, then rock gently to check that it's locked before use.




- 2.Turn the turning mechanism to the left, lift up the tube, and fold back the handlebar if needed..

— Height Adjustment and Brake



Put the foot on the brake to slow down the speed until it stops.



Caution notes

1. Avoid driving in the rain, and do not soak or wash the scooter with water.
2. Parts from other manufacturers are prohibited.
3. Please use the scooter under adult supervision to avoid danger.
4. Avoid bumping and squeezing the scooter during driving.
5. Please use the scooter on flat roads to reduce wheel wear.
6. A recommendation to use protective equipment such as a helmet, gloves, knee-pads and elbow-pads.




Warnings

- A reminder that the toy shall be used with caution, since skill is required to avoid falls or collisions causing injury to the user or third parties.
- Protective equipment should be worn. Not to be used in traffic. Scooter 50kgs/110lbs max, Seat 25kgs/55lbs max.
- To be used under the direct supervision of an adult.Assembly should only be done by adults.
- This manual contains important information.Please read it carefully and keep it.

Maintenance:


1. Check over all the parts regularly, and clean in between the parts to ensure normal use of the scooter and to prevent injuries.
2. Please clean up the scooter after use, and keep it in a cool and dry place; place away from direct sunlight to avoid aging and discoloration.

— seat installation method




Position bar can only be placed in the installation hole

1. Open the switch, then open the front cover and side cover, as needed install Position bar into the hole.




2. Front cover and side cover fixed on the pole, fix the switch into slot. Press the switch to secure the seat on the pole.

— Seat disassembly method



Open the switch with the side cover, then open the front cover, the seat can be removed.

— Seats' folding



Folding the seat up and down, to switch seat's state.