


Assembly Instructions



Warning Notice




- Please keep this manual and provide it to the new owner if you transfer the product.
- Please read the following instructions carefully before use.
- This manual may not cover every detail of all variations or all possible steps.
Contact us if you need further information or assistance.
- Do not exceed the weight limitations of this product.
- Do not stand on this item or use any part of it as a step ladder.
- If any parts are missing, broken, damaged, or worn, stop using the item immediately.
Do not use until repairs are made or factory replacement parts are installed.
- Assemble the item in a spacious area. Do not place the unwrapped product directly on the floor to avoid damage.
- Using this product in a manner inconsistent with the manufacturer's instructions may void the warranty.
- Periodically check the tightness of all screws during use. Retighten them if necessary to maintain structural integrity.
- To avoid suffocation hazards, keep all packaging materials (plastic film, bags, foam, etc.) away from children and pets.
- Do not use or store this item near open flames or flammable/combustible chemicals.
- Do not expose the product to direct sunlight, rain, or excessive humidity, as this may cause distortion or discoloration.

IMPORTANT

- Do not fully tighten bolts/screws until all are aligned and inserted into their respective holes.
- Do not over-tighten screws and bolts, as this can strip the threads.
- Use hand tools for assembly. If you must use power tools, set them to a very low torque setting to avoid damaging the product.


Before You Start



--Open your item in the area you plan to keep it for less heavy lifting.



--Identify, sort, and count the parts before attempting assembly.



--Lay all parts on smooth flat surface.




--Do NOT use harsh chemicals or abrasive cleaners on this item.




--Use hand tools for assembly. If you must use power tools, set them to a very low torque setting to avoid damaging the product.

Components


A*1




B*1




C*1




D*1




E*1




F*1




G*1




H*1



I*1



J*5




K*4

M6*20MM



L*2


M6*25MM




M*1

Assembly Instructions


- ① Insert the 5 castors to the chair base (I+J)




- ② Insert the gas lift to the chair base (G+I)



- ③ Loosen the footrest knob, insert the gas lift to the footrest. And then tighten the knob to secure it (H+G)




- ④ Install the mechanism on the seat (D+B)




Assembly Instructions


- ⑤ Install the mounting bracket on the top of the backrest link bar (C+F)



- ⑥ Cover the cap to the bracket (E+F). Fix the components on the backrest with screws (L+A).



- ⑦ Connect the link bar with the mechanism and fix by the knob (C+D)



- ⑧ Install the seat to the gas lift (D+G)

