




Unit Information

One Piece Dishwasher Safe Removable Jar Pad





032761

MX Jar Wrench
(optional)

Illustration#	Part#	Description
1	026425-E	Eastman Jar Lid Cover
2	026424-V	Vinyl Jar Lid
3	030888	48 oz. Raptor Container ONLY
	503439	48 oz. Raptor Container with Blending Assembly
4	503397	Blade Assembly
5	024271	Bearing Holder O Ring
6	024268	Nut Gasket
7	029631	Bearing Holder Nut
8	028538	Drive Coupling
9	026442	Jar Pad
10	035396	Leili Motor without Sensor <i>(on units after 7/27/2017)</i>
	028100	ECM Motor without Sensor
11	026437	Dampening Plate Gasket
12	028032-09	Black Top Housing
13	028541	Motor Foam (2 required)
14	026439	Dampening Plate Bushing (4 required)
15	026453	Dampening Plate Sleeve (4 required)
16	026459	Washer
17	028929	Sems (4 required)
18	036398	Control Panel with Interlock <i>(on units after 8/7/2018)</i>
	029810	Soft Start Control Panel (use 036398)
19	028248	Top Housing Foam Rear Baffle
20	028249	Top Housing Foam Front Baffle
21	036814	Motor Housing 2.78" <i>(on units after 5/16/2019)</i>
	028240-67	Motor Housing 67 mm <i>(on units after 7/27/2017)</i>
	028240	Motor Housing 60 mm
22	002943	Washer (2 required)
23	026925	Cord Set
24	007556	Strain Relief
25	034900	PCB Cushion (2 required <i>on units after 5/16/2019</i>)
26	037232	Neoprene Washer <i>(on units after 5/16/2019)</i>
27	037007	PCB Mounting Bracket <i>(on units after 5/16/2019)</i>
28	013768	Screw <i>(on units after 5/16/2019)</i>
29	028247	Bottom Housing Foam Baffle

Illustration#	Part#	Description
30	028542	Foam Baffle
31	028241-09-X	Black Bottom Housing
32	012505	Screw (4 required)
33	026430	Corner Post (4 required)
34	028928	Sems (4 required)


033483
 Brush/Spring for ECM motor 028100
 (2 required)



503144
 SE500 (optional)