
ACCENT CHAIR











with OTTOMAN



WARRANTY

- All warranties are to the original purchaser
- We will replace the defective parts or send replacement item provided that the warranty parts have not been subjected to misuse, abuse or improper service by the consumer, for example, damaged wire arising in consequence of negligence or improper operation.
- All of chairs come with a 30-day return/replace policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged item, through provide pre-paid return label or pick up service for customer's convenience.

PARTS LIST




Please remove all protective foam.

Assemble the Chair


Step 1

Fasten the 4 legs (#E&#F) of the chair under the seat cushion (#A) with screws (#C&#D).




Step 2

Fasten the backrest and seat cushion together with screws (#G &#D&#H).



Step 3

Fasten the 4 legs (#J) of the ottoman under the ottoman cushion (#I) with screws (#C&#D).



Congratulations!

Step 4

Finally, put the lumbar pillow (#B) on the chair or ottoman and enjoy it!

