


Modern 4-Door Accent Cabinet



After-sales mailbox:
Homefurnitureserviceteam@outlook.com

NOTICE

Please keep these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems



F . Other aspects that you are not satisfied with




Please feel free to contact us for help. Our after-sales team service



(**Homefurniture Serviceteam@outlook.com**) will reply within 24 hours and will do our best to resolve the problem for you.



PART LIST





A	X56	B	X56	C	X26	D	X2	E	X1
									
Ø6X35mm		Ø15X12mm		Ø8X30mm		φ7X47mm		M4X55mm	

F	X8	G	X58	H	X2	I	X8	J	X2
									
M6X38mm		Ø3.5X14mm		Ø4X35mm		Ø5X13mm		Ø8X40mm	


K	X2	L	X7	M	X8	N	X4	O	X4
									
155X20mm		Ø20mm		14X14X9mm					

REMARK:

MINIFIX POSITION




EXPLODED DRAWING




STEP

01





02




STEP

03




C	X2	D	X2	E	X1
					
Ø8X30mm		φ7X47mm		M4X55mm	

04




B	X3	C	X2
			
Ø15X12mm		Ø8X30mm	


05



06




07




B	X7	C	X2
			
Ø15X12mm		Ø8X30mm	

08




B	X7	C	X2
			
Ø15X12mm		Ø8X30mm	

09



B	X6	C	X4
			
Ø15X12mm		Ø8X30mm	


10




B	X21	C	X6
			
Ø15X12mm		Ø8X30mm	

STEP


11




12




13




X2








C	X4	F	X4
			
Ø8X30mm		M6X38mm	

14




X2




C	X4	F	X4
			
Ø8X30mm		M6X38mm	

15



G	X8	O	X4
			
Ø3.5X14mm			



16



G	X8	N	X4
			
Ø3.5X14mm			


STEP

17




G	X16
	
Ø3.5X14mm	

18




G	X16
	
Ø3.5X14mm	

19



20



AFTER-SALE SERVICE

If you have any suggestions for our products or notice any quality issues, please contact us first. Our after-sales team will respond within 24 hours and will do everything possible to provide you with a satisfactory solution.

Guaranteed Customer Service

Your shopping experience is very important to us!

Feel unsatisfied? **Contact us!**

Have any questions? **Contact us!**

Wanna Share how wonderful our smart products make your home?

Share your pictures with us.

Any suggestions? **Contact us!**

We will check and give feedback.



Homefurniture Serviceteam@outlook.com

