



























CORNER COAT RACK

MONTAJ KLAVUZU / ASSEMBLY MANUAL







AKSESUAR LİSTESİ / ACCESSORY LIST

A23  6x	A22  18x	A04  8x30	A14  86 mm	K26  1x										
A61  4x	A18  8x	C02  2x	C04  2x	A49  1x										
A41  12x	A17  29x	A20  8x	F05  4x	A10  17x										
A10  12x	A06  12x	A06  6x	<table border="0"> <tr> <td>1.RNK</td> <td>2.RNK</td> </tr> <tr> <td>ATLANTİK - ANTRASİT</td> <td>ATLANTİK - BUTE BEJ</td> </tr> <tr> <td>ATLANTİK - BEYAZ</td> <td>ATLANTİK - ATLANTİK</td> </tr> <tr> <td>ANTRASİT - ANTRASİT</td> <td>BEYAZ - BEYAZ</td> </tr> <tr> <td>LİDYA - LİDYA</td> <td>BUTE BEJ - BUTE BEJ</td> </tr> </table>		1.RNK	2.RNK	ATLANTİK - ANTRASİT	ATLANTİK - BUTE BEJ	ATLANTİK - BEYAZ	ATLANTİK - ATLANTİK	ANTRASİT - ANTRASİT	BEYAZ - BEYAZ	LİDYA - LİDYA	BUTE BEJ - BUTE BEJ
1.RNK	2.RNK													
ATLANTİK - ANTRASİT	ATLANTİK - BUTE BEJ													
ATLANTİK - BEYAZ	ATLANTİK - ATLANTİK													
ANTRASİT - ANTRASİT	BEYAZ - BEYAZ													
LİDYA - LİDYA	BUTE BEJ - BUTE BEJ													


PARÇA KODLAMA / DISASSEMBLED VIEW




1




2





3




4








6



7





KAPAK AYAR ŞEMASI Door setting chart

