
Christmas Tree Installtion Instruction



3XAA BATTERY

4 FT/120 CM



3XAA BATTERY



3XAA BATTERY

Note:

1. Fill the pots with sandy soil to increase stability.
2. Fluff and shape the branches after connecting the tree sections. This may require gently pulling them outward & downward as bracnhes can get tangled during shipping.
3. Be careful not to pinch any of the light wires (if applicable) between the hinge when shaping the branches.
4. When not in use, store neatly in a cool, dry location protected from sunlight.