


Coffee Table

Assembly Instruction-please keep for future reference



Dimensions

Width-47.2inch

Depth-23.6inch

Height-15.7inch

Important-please read this instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING

In order to help prevent overturning – please follow these instructions


To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.





Step 4

















Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.













The joint is now secure.








①  1200mm*600mm*15mm 1PC	②  1200mm*600mm*15mm 1PC	③  270mm*598mm*15mm 1PC
④  270mm*598mm*15mm 1PC	⑤  270mm*560mm*15mm 1PC	⑥  270mm*576mm*15mm 1PC
⑦  576mm*100mm*15mm 1PC	⑧  200mm*100mm*15mm 4PC	⑨  200mm*100mm*15mm 4PC
⑩  520.5mm*100mm*15mm 4PC	⑪  184mm*50mm*15mm 4PC	⑫  588.5mm*131.5mm*18mm 2PC
⑬  588.5mm*131.5mm*18mm 2PC	⑭  266mm*285mm*19mm 4PC	⑮  528.5mm*192mm*3mm 4PC
Hardware Box  1PC		

Hardware List

A A₁  Cam Bolt=36+1PCS		A₂  Cam Lock=36+1PCS	B  Ø8*40 Dowel=14+1PCS	C  M7*50 Screw= 8+1PCS
E  Sliding Rail=200MM 8PC 				
D  Hinge =8PCS	F  Handle=4PCS	G  M4*22 Screw= 8PCS	H  M3.5*35 Screw= 20+1PCS	
I  M3.5*14 Screw= 88+2PCS	J  Catch=2PCS	K K₁  Tape Lights=1PCS K₂  Screw= 5PCS		
L  Beauty patch=28PCS	M  Leg = 5PCS			


Tool Required	
	
	

Step 1





	A ₁ x4pcs		E ₁ x4pcs
	Ix8pcs		Bx8pcs

Step 2




	A ₁ x4pcs		E ₁ x4pcs
	Ix8pcs		Bx6pcs

Step 3




	$A_2 \times 4 \text{ pcs}$
	$L \times 4 \text{ pcs}$

Step 4






A₂x4pcs

Step 5




	A ₁ x8pcs		
	Ix4pcs		K ₁ x1pcs
	Jx2pcs		K ₂ x5pcs

Step 6




	A ₂ x8pcs
	Lx8pcs

Step 7



Cx8pcs

Step 8




Ix20pcs




Mx5pcs

Step 9



Such screws are included in the hinge packaging bag





X4



Dx8pcs

Step 10




Ix32pcs


If the door can't close, please adjust the hinges.

Step 11


To adjust the door vertically loosen the screw as shown and move up and down as needed.




To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.




To adjust the door laterally adjust the screw as shown by turning clockwise or anti-clockwise.



Please fix other screws




Step 12



A₁x20pcs

Step 13




A₂x20pcs




Lx16pcs

Step 14




Step 15




Hx20pcs

Step 16




	I x 16 pcs
	E ₂ x 8 pcs

Step 17




	F x 4 pcs
	G x 8 pcs

Step 18



Step 19



DE:Wenn Sie die Lichter nicht erfolgreich arbeiten lassen können, überprüfen Sie bitte die Folgendes:

1. Bitte überprüfen Sie die Fernbedienung. Sie müssen die Fernbedienung abreißen Plastikseptum vor Gebrauch.
2. Lassen Sie die Fernbedienung nicht zu weit vom Empfänger entfernt sein Es gibt kein Hindernis zwischen ihnen.
- 3.Bitte beachten Sie, dass die Fernbedienung für den Transport keine Batterien enthält. Das Batteriemodell lautet: CR2025

FR: Si vous ne parvenez pas à faire fonctionner les lumières correctement, veuillez vérifier les points suivants?:

1. Veuillez vérifier la télécommande. Vous devez retirer le septum en plastique de la télécommande avant utilisation.
2. Ne laissez pas la télécommande être trop éloignée du récepteur. Il n'y a aucun obstacle entre eux.
3. Veuillez noter que la télécommande ne contient pas de piles pour le transport. Le modèle de batterie est?: CR2025

UK: If you can't make the lights work successfully, please check the following:

1. Please check the remote control. You need to tear off the remote plastic septum before use.
2. Don't let the remote control be too far from the receiver There is no obstacle between them.
- 3.Please note that the remote control does not contain batteries for transportation. The battery model is: CR2025

Manufacturer's name:Dongguan Huima Synthetic Electronics Co.,Ltd

Model:LED5050X60

FCC ID:2BEMSHMLY

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

TCB

GRANT OF EQUIPMENT
AUTHORIZATION

TCB

Certification

Issued Under the Authority of the
Federal Communications Commission

By:

Eurofins Electrical and Electronic Testing NA,
Inc.
914 W. Patapsco Avenue
Baltimore, MD 21230-3432

Date of Grant: 08/14/2025

Application Dated: 08/14/2025

Dongguan Huima Synthetic Electronics Co.,Ltd
3rd Floor, Bingding A, No.1 Jiangxing Road,
Huangjiang Village, Huangjiang Town,
Dongguan City, Guangdong Province,
China

Attention: make zhang ,

NOT TRANSFERABLE

EQUIPMENT AUTHORIZATION is hereby issued to the named GRANTEE, and is VALID ONLY for the equipment identified hereon for use under the Commission's Rules and Regulations listed below.

FCC IDENTIFIER: 2BEMSHMLY

Name of Grantee: Dongguan Huima Synthetic Electronics
Co.,Ltd

Equipment Class: Digital Transmission System
Notes: 2.4G controller

<u>Grant Notes</u>	<u>FCC Rule Parts</u>	<u>Frequency Range (MHZ)</u>	<u>Output Watts</u>	<u>Frequency Tolerance</u>	<u>Emission Designator</u>
	15C	2402.0 - 2480.0	0.00071		

Output Power listed is conducted. The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter, except in accordance with FCC multi-transmitter product procedures.