



ASSEMBLY INSTRUCTIONS

GOLD DINING CHAIR MATTE BLACK DINING CHAIR



+ Do Not Use PowerTools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:

Part ① Backrest

Part ② Left Leg

Part ③ Right Leg

Do not assemble if any of the following Hardware parts are missing:

Part A Bolt(1/4"*1-5/8")

Part B Spring Washer 1/4"

Part C Flat Washer 1/4"


Part D Allen Key(4mm)

2 IMPORTANT ASSEMBLY INFORMATION


Assembly Step If loosening persists, Please make sure to tighten all the bolts periodically, or use a thread locker adhesive.

+ Parts Included


- ① Backrest
1PC



- ② Left Leg
1PC



- ③ Right Leg
1PC



+ Hardware Included

A Bolt(1/4"*1-5/8") B Spring Washer 1/4"

6 PCS

6 PCS



C Flat Washer 1/4" D Allen Key(4mm)

6 PCS


1 PC



ASSEMBLY INSTRUCTIONS


GOLD DINING CHAIR MATTE BLACK DINING CHAIR

①



Note: At this stage, do not fully tighten the bolts.

②



③

