

Assembly Instruction

ASSEMBLY TIPS:

1.Remove hardware from box and sort by size.

2.Please check to see that all hardware and parts are present prior to start of assembly. 3.please follow attached instructions in the same sequence as numbered to assurefast & easy assembly.

▲ Warning!

1.Don't attempt to repair or modify parts that are broken or defective.Please contsct the store immediately.

2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION: 1PC (A) TOP (B) PILLAR 8PCS 2PCS (C) LEG (D) SHELF 1PC

ASSEMBLY INSTRUCTION

Ζ	HARDWARE PACKAGE:		
NO	DESCRIPTION	FIGURE	QTY
1	SCREW		4pcs
2	STUD BOLT ゆ 5/16*(10+65)mm	all marks	4pcs
3	CHROMED WASHER Φ5/16*55mm	\bigcirc	8pcs
4	BIG WASHER Ф5/16*50mm	(P)	4pcs
5	FLAT WASHER Φ5/16*20mm	6	4pcs
6	ALLEN BOLT		4pcs
7	SMALL WASHER	•	4pcs
8	ALLEN WRENCH Ф5/16*66mm		1pc


STEP 1:Place top upside down on a soft and scratch resistant surface, then spin screws(part"1") into four holes on the top. Align and spin pillars (part"B") in screws. Then screw stud bolts (part"2") into the other side of the pillars. Put chromed washers (part"3") through the bolts with grooved sides towards bolts. Then insert two legs(part"C"), big washers (part"4") and last pillars(part"B") in each bolt. Finally revolve pillars till steady.

 1
 I
 4PCS

 2
 I
 4PCS

 3
 I
 4PCS

 4
 I
 4PCS



ASSEMBLY INSTRUCTION

