


















Suggestion

- It is recommended to install it near a power source, as later steps will require the power to be turned on.
- This product requires installation by at least two people.

ASSEMBLY INSTRUCTION




ASSEMBLY INSTRUCTION

①  1PC	②  1PC	③  2PCS	④  2PCS
⑤  2PCS	⑥  1PC	⑦  1PC	⑧  2PCS
⑨  1PC	⑩  1PC	⑪  2PCS	⑫  2PCS
⑬  1PC	⑭  1PC	⑮  1PC	⑯  1PC
⑰  1PC	⑱  1PC	⑲  1PC	⑳  1PC

ASSEMBLY INSTRUCTION


②1

1PC




②2

1PC




②3

1PC




②4

1PC




②5

1PC




②6

1PC




②7

1PC




②8

1PC




②9

1PC




③0

1PC




③1

1PC




③2

1PC




③3

1PC




③4

1PC



③5

1PC




③6

1PC




③7

1PC




③8

1PC




③9

1PC






















④0



1PC







ASSEMBLY INSTRUCTION

④1 1PC 	④2 1PC 	④3 2PCS 	④4 1PC 
④5 1PC 	④6 2PCS 	④7 2PCS 	④8 3PCS 
④9 2PCS 	⑤0 1PC 	⑤1 1PC 	⑤2 1PC 
⑤3 1PC 	⑤4 2PCS 	⑤5 1PC 	⑤6 1PC 
⑤7 1PC 	⑤8 1PC 	⑤9 1PC 	⑥0 1PC 







ASSEMBLY INSTRUCTION

⑥1	1PC	⑥2	2PCS	⑥3	1PC	⑥4	2PCS
							

"A" Hardware installation example

I	II
	
III	IV
	

ASSEMBLY INSTRUCTION
















A 12PCS  M6*30	B 10PCS  M6*10	C 1PC  M4	D 4PCS  M6*10
E 6PCS  14"	F 2PCS  M8	G 1PC 	H 4PCS 
I 1PC 	J  4PCS  8PCS	K 125PCS  M6*40	L 125PCS  Ø15*9.5
M 88PCS  Ø3.5*14	N 12PCS  Ø3.5*40	O 12PCS  Ø5*15	P 8PCS 
Q 1set  Q1  Q2  Q3  Q4  Q5  Q6	R 16PCS 	S 2PCS  Ø50	T 1PC 
U 11PCS  Ø8*40	V 2PCS 	W 16PCS  M6*16	X 2PCS  M8*16
Y 8PCS  M8*90	Z 16sets  Z1  Z2  Z3  Z4 M8	125PCS 	 M4  M5  

Step 1

K 113PCS






M6*40





Step 2

K 12PCS
M6*40




Step 3

L 3PC
Ø15*9.5



Step 4

L 2PCS
Ø15*9.5




ASSEMBLY INSTRUCTION

Step 5

L 1PC


Ø15*9.5



Step 6

L 5PCS


Ø15*9.5



Step 7

L 2PCS


Ø15*9.5



Step 8

L 10PCS

Ø15*9.5




ASSEMBLY INSTRUCTION

Step 9

L 6PCS

 Ø15*9.5




Step 10

G 1PC

 M 2PCS


 Ø3.5*14



Step 11

L 11PCS



 Ø15*9.5





Step 12

M 4PCS



 Ø3.5*14






Step 13





Step 14




Step 15



Step 16




Step 17



Step 18


M 8PCS
Ø3.5*14



Please press here
to open the door
panel.


Step 19

L 3PCS
Ø15*9.5



Step 20

L 3PCS
Ø15*9.5




ASSEMBLY INSTRUCTION

Step 21

L 6PCS


 Ø15*9.5



Step 22

L 4PCS


 Ø15*9.5



Step 23

L 4PCS


 Ø15*9.5



Step 24


L 7PCS

 Ø15*9.5




Step 25

E 6PCS



Ex6




Step 26

M 12PCS



Ø3.5*14

E1 6PCS




ASSEMBLY INSTRUCTION

Step 27

L 5PCS


 Ø15*9.5



Step 28

L 5PCS


 Ø15*9.5



Step 29

L 12PCS


 Ø15*9.5



Step 30

L 18PCS



 Ø15*9.5



Step 31


M 4PCS

 Ø3.5*14




Make sure the accessory nuts face outward during installation.

Step 32





A	4PCS
	M6*30
Q5	1PC
Q6	2PCS
	Ø3.0*15





Step 33





R	10PCS







E2 2PCS  14"	L 4PCS  Ø15*9.5
M 4PCS  Ø3.5*14	N 4PCS  Ø3.5*40
Q 1set  Q1  Q2  Q3  Q4  Q5	



E2 2PCS  14"	L 4PCS  Ø15*9.5
M 4PCS  Ø3.5*14	N 4PCS  Ø3.5*40





Step 36




E2	2PCS	L	4PCS
			
14"		Ø15*9.5	
M	4PCS	N	4PCS
			
Ø3.5*14		Ø3.5*40	

Step 37




Step 38

0 8PCS
Ø5*15



Step 39


M 8PCS
Ø3.5*14
P 4PCS



Step 40

M 16PCS


Ø3.5*14



Step 41


L 6PCS

Ø15*9.5




Step 42


Attention, please! Lift accessory 1 and accessory 2 up by hand to the same level to facilitate the installation of accessory 5 in step 43.



Step 43



Note that the "gourd-shaped hole" here on the front crossbeam is close to the left cabinet




First install the inner screw, then install the outer screw.

B	4PCS
	
	M6*10
C	1PC
	
	M4


Step 44

If it is not pushed all the way to the bottom, it may cause the product to have uneven legs, which can result in an uneven tabletop.

Attention, please! Install accessory 5, which is the crossbeam, and press the legs on both sides to the lowest position.




Step 45




Step 46


B 2PCS
M6*10



Step 47




Step 48



C	1PC
	M4
F	2PCS
	M8
I	1PC

Note: If the transmission rod doesn't fit smoothly into the hole of rod coupler, fine-tune fit with the wrench.

Step 49




Step1: Connect the controller of the lifting frame, namely accessory 6, to the plugs of the other two accessories 10 and 13, and then turn on the power.

Step2: Press the downward button on the controller for 5 seconds- the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.


Step3: Press and hold the "Rise" button, raise the lifting frame to a certain height, then turn off the power and proceed to the next installation step.

Step 50




Step 51

B 4PCS
M6*10




Step 52

A 4PCS
M6*30



Step 53


D 4PCS
M6*10



Step 54

The tabletop is too heavy. It is recommended to move the two boards here to the tabletop and then join them together.

U 4PCS
Ø8*40





Step 55

W 16PCS
M6*16


Attention, please! At this step, screw W cannot be locked yet. All 16 screws need to be locked before tightening screw W uniformly.

Wx16




Step 56

S	2PCS	M	2PCS
			
Ø50		Ø3.5*14	



Step 57



To prevent the power adapter from being damaged and from loosening, please use a pull strap to secure the cable.


H	4PCS
	
M	4PCS
	
	Ø3.5*14
T	1PC
	

Step 58


X2PCS



M8*16



Step 59



OK

Instruction Manual for JCB35M51C Controller (Version 1.0-English)


System Function Description:

1. Lifting and Lowering Function of the Height-Adjustable Desk:

Hold down the upward button, and the column will rise; hold down the downward button, and the column will lower. Release the button, and the movement will stop.

2. Memory Position Function:

Long press the "①/②" button for 3 seconds until the digital tube display flashes. After the number flashes 3 times and stops, the current height will be successfully stored in the corresponding memory position. Short press the "①/②" button and release it, and the tabletop will automatically move to the height of the memory position. During operation, pressing any button can stop the movement.



3. Reset Function:

(1) Function Description:

The system needs to be reset under specific circumstances.

These circumstances include:

- ① When used for the first time, the system will enter the reset state after being powered on.
- ② Active reset will put the system into the reset state.
- ③ A system abnormality will cause the system to enter the reset state.

(2) Operation Method:

Bottom Reset: Hold down the downward button until it reaches the bottom. Then release the button, and press the downward button again for 5 seconds—the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.

